

Dell EMC PowerEdge R840

Installation and Service Manual

Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

Chapter 1: About this document.....	7
Chapter 2: Dell EMC PowerEdge R840 system overview.....	8
Front view of the system.....	8
Control panels.....	9
LCD panel.....	10
Rear view of the system.....	12
Inside the system.....	13
Locating the Service Tag of your system.....	14
System Information Label.....	15
Chapter 3: Initial system setup and configuration.....	19
Setting up your system.....	19
iDRAC configuration.....	19
Options to set up iDRAC IP address.....	19
Log in to iDRAC.....	20
Options to install the operating system.....	20
Methods to download firmware and drivers.....	20
Downloading drivers and firmware.....	21
Chapter 4: Installing and removing system components.....	22
Safety instructions.....	22
Before working inside your system.....	23
After working inside your system.....	23
Recommended tools.....	23
Optional front bezel.....	24
Removing front bezel.....	24
Installing the front bezel.....	24
System cover.....	25
Removing the system cover.....	25
Installing system cover.....	26
Air shroud.....	28
Removing the non-GPU air shroud.....	28
Installing the non-GPU air shroud.....	28
Removing the GPU air shroud.....	29
Installing the GPU air shroud.....	31
Cooling fan assembly.....	32
Removing the cooling fan assembly.....	32
Installing the cooling fan assembly.....	33
Cooling fans.....	34
Removing a cooling fan.....	34
Installing a cooling fan.....	35
NVDIMM-N battery.....	36
Removing the NVDIMM-N battery.....	36

Installing NVDIMM-N battery.....	38
Drives.....	39
Removing a drive blank.....	39
Installing a drive blank.....	40
Removing a drive carrier.....	40
Installing a drive carrier.....	41
Removing the drive from the drive carrier.....	42
Installing a drive into the drive carrier.....	43
Rear drive cage.....	44
Removing the rear drive cage.....	44
Installing the rear drive cage.....	45
System memory.....	46
General memory module installation guidelines.....	48
NVDIMM-N memory module installation guidelines	49
PMem installation guidelines	52
Mode-specific guidelines.....	55
Removing a memory module.....	58
Installing a memory module.....	59
Expansion cards and expansion card risers.....	60
Expansion card installation guidelines.....	60
Removing expansion card from the expansion card riser.....	66
Installing expansion card into the expansion card riser.....	68
Removing the expansion card risers.....	70
Installing the expansion card risers.....	73
Removing a PCIe expansion card.....	75
Installing a PCIe expansion card.....	77
GPU card installation guidelines.....	78
Removing a GPU.....	78
Installing a GPU.....	79
Optional M.2 SSD module.....	80
Removing the M.2 SSD module.....	80
Installing the M.2 SSD module.....	81
Processors and heat sinks.....	82
Removing a processor and heat sink module.....	83
Removing the processor from the processor and heat sink module.....	84
Installing the processor into a processor and heat sink module.....	85
Installing a processor and heat sink module.....	88
Optional IDSDM or vFlash module.....	90
Removing IDSDM or vFlash module.....	90
Installing IDSDM or vFlash module.....	91
Removing the MicroSD card.....	91
Installing the MicroSD card.....	92
Network daughter card.....	93
Removing network daughter card.....	93
Installing network daughter card.....	94
Drive backplane.....	95
Drive mapping.....	96
Removing drive backplane	97
Installing drive backplane.....	98
Cable routing.....	100

System battery.....	105
Replacing system battery.....	105
Optional USB 3.0 module.....	106
Removing USB 3.0 module.....	106
Installing USB 3.0 module.....	107
Optional internal USB memory key.....	108
Replacing optional internal USB memory key.....	108
Optional optical drive.....	109
Removing optical drive.....	109
Installing optical drive.....	110
Power supply units.....	111
Hot spare feature.....	112
Removing a power supply unit blank.....	112
Installing a power supply unit blank.....	112
Removing power supply unit.....	113
Installing power supply unit.....	114
Wiring instructions for a DC power supply unit.....	115
Power Interposer Board.....	116
Removing Power Interposer Board.....	116
Installing Power Interposer Board.....	117
System board.....	118
Removing system board.....	118
Installing system board.....	119
Restore the service tag using Easy Restore.....	121
Manually updating Service Tag.....	121
Trusted Platform Module.....	122
Upgrading Trusted Platform Module.....	122
Initializing TPM for BitLocker users.....	123
Initializing the TPM 1.2 for TXT users.....	123
Control panel.....	123
Removing left control panel.....	123
Installing left control panel.....	124
Removing right control panel.....	125
Installing right control panel.....	126
Chapter 5: Jumpers and connectors	128
System board connectors.....	129
System board jumper settings.....	131
Disable a forgotten password.....	132
Chapter 6: System diagnostics and indicator codes	133
Status LED indicators.....	133
System health and system ID indicator codes.....	134
iDRAC Quick Sync 2 indicator codes.....	134
iDRAC Direct LED indicator codes.....	135
NIC indicator codes.....	135
Power supply unit indicator codes.....	136
Drive indicator codes.....	138
System diagnostics.....	139

Dell Embedded System Diagnostics.....	139
Chapter 7: Getting help.....	141
Contacting Dell.....	141
Documentation feedback.....	141
Accessing system information by using QRL.....	141
Receiving automated support with SupportAssist	142
Quick Resource Locator for PowerEdge R840 system.....	142
Recycling or End-of-Life service information.....	142
Chapter 8: Documentation resources.....	143

About this document

This document provides an overview about the system, information about installing and replacing components, technical specifications, diagnostic tools, and guidelines to be followed while installing certain components.

Dell EMC PowerEdge R840 system overview

The Dell EMC PowerEdge R840 system is a 2U server that supports up to:

- Four Intel Xeon scalable processors
- 48 DIMM slots
- Two AC or DC power supply units
- 26 SAS, SATA, Nearline SAS hard drives or SSDs including two rear accessible drives.

For more information, see the Dell EMC PowerEdge R840 Technical Specifications on the product documentation page.

NOTE: All instances of SAS, SATA hard drives, NVMe and SSDs are referred to as drives in this document, unless specified otherwise.

Topics:

- [Front view of the system](#)
- [Rear view of the system](#)
- [Inside the system](#)
- [Locating the Service Tag of your system](#)
- [System Information Label](#)

Front view of the system




Figure 1. Front view 24 x 2.5-inch drive system

- | | |
|------------------------|----------------|
| 1. Left control panel | 2. Drives |
| 3. Right control panel | 4. Service Tag |




Figure 2. Front view 8 x 2.5-inch drive system

- | | |
|-----------------------------|----------------------------|
| 1. Left control panel | 2. Drive slots |
| 3. Optical drive (Optional) | 4. USB 3.0 port (Optional) |
| 5. Right control panel | 6. Service Tag |

For more information, see the Dell EMC PowerEdge R840 Technical Specifications on the product documentation page.

Control panels

Left control panel




Figure 3. Left control panel view (with optional iDRAC Quick Sync 2.0 indicator)

1. Status LED indicators
2. System health and system ID indicator
3. iDRAC Quick Sync 2 wireless indicator (optional)

NOTE: iDRAC Quick Sync 2 feature allows you to manage your system using mobile devices. This feature is only available on certain configurations. For more information about the feature, see the Integrated Dell Remote Access Controller User's Guide at www.dell.com/idracmanuals.

Right control panel view




Figure 4. Right control panel view

- 1. Power button
- 2. USB 2.0 port (2)
- 3. iDRAC Direct port
- 4. iDRAC Direct LED
- 5. VGA port

NOTE: For more information on the ports, see the PowerEdge R840 Technical Specs at www.dell.com/poweredgemanuals.

LCD panel

The LCD panel provides system information, status, and error messages to indicate if the system is functioning correctly or requires attention. The LCD panel can also be used to configure or view the system's iDRAC IP address. For information about the event and error messages generated by the system firmware and agents that monitor system components, go to qrl.dell.com > **Look Up** > **Error Code**, type the error code, and then click **Look it up**.

The LCD panel is available only on the optional front bezel. The optional front bezel is hot pluggable.

The statuses and conditions of the LCD panel are outlined here:

- The LCD backlight is white during normal operating conditions.
- When the system needs attention, the LCD backlight turns amber, and displays an error code followed by descriptive text.
- **NOTE:** If the system is connected to a power source and an error is detected, the LCD turns amber regardless of whether the system is turned on or off.
- When the system turns off and there are no errors, LCD enters the standby mode after five minutes of inactivity. Press any button on the LCD to turn it on.
- If the LCD panel stops responding, remove the bezel and reinstall it. If the problem persists, see the PowerEdge T640 Technical Specs at www.dell.com/poweredgemanuals
- The LCD backlight remains off if LCD messaging is turned off using the iDRAC utility, the LCD panel, or other tools.



Figure 5. LCD panel features

Table 1. LCD panel features

Item	Button or display	Description
1	Left	Moves the cursor back in one-step increments.
2	Select	Selects the menu item highlighted by the cursor.

Table 1. LCD panel features (continued)

Item	Button or display	Description
3	Right	Moves the cursor forward in one-step increments. During message scrolling: - Press and hold the right button to increase scrolling speed. - Release the button to stop.  NOTE: The display stops scrolling when the button is released. After 45 seconds of inactivity, the display starts scrolling.
4	LCD display	Displays system information, status, and error messages or iDRAC IP address.

Viewing Home screen

The **Home** screen displays user-configurable information about the system. This screen is displayed during normal system operation when there are no status messages or errors. When the system turns off and there are no errors, LCD enters the standby mode after five minutes of inactivity. Press any button on the LCD to turn it on.

Steps

- To view the **Home** screen, press one of the three navigation buttons (Select, Left, or Right).
- To navigate to the **Home** screen from another menu, complete the following steps:
 - Press and hold the navigation button until the up arrow  is displayed.
 - Navigate to the **Home** icon  using the up arrow .
 - Select the **Home** icon.
 - On the **Home** screen, press the **Select** button to enter the main menu.

Setup menu

 **NOTE:** When you select an option in the **Setup** menu, you must confirm the option before proceeding to the next action.

Option	Description
iDRAC	Select DHCP or Static IP to configure the network mode. If Static IP is selected, the available fields are IP , Subnet (Sub) , and Gateway (Gtw) . Select Setup DNS to enable DNS and to view domain addresses. Two separate DNS entries are available.
Set error	Select SEL to view LCD error messages in a format that matches the IPMI description in the SEL. This enables you to match an LCD message with an SEL entry. Select Simple to view LCD error messages in a simplified user-friendly description. For information about the event and error messages generated by the system firmware and agents that monitor system components, go to qrl.dell.com > Look Up > Error Code, type the error code, and then click Look it up.
Set home	Select the default information to be displayed on the Home screen. See View menu section for the options and option items that can be set as the default on the Home screen.

View menu

 **NOTE:** When you select an option in the **View** menu, you must confirm the option before proceeding to the next action.

Option	Description
iDRAC IP	Displays the IPv4 or IPv6 addresses for iDRAC9. Addresses include DNS (Primary and Secondary) , Gateway , IP , and Subnet (IPv6 does not have Subnet).

Option	Description
MAC	Displays the MAC addresses for iDRAC , iSCSI , or Network devices.
Name	Displays the name of the Host , Model , or User String for the system.
Number	Displays the Asset tag or the Service tag for the system.
Power	Displays the power output of the system in BTU/hr or Watts. The display format can be configured in the Set home submenu of the Setup menu.
Temperature	Displays the temperature of the system in Celsius or Fahrenheit. The display format can be configured in the Set home submenu of the Setup menu.

Rear view of the system




Figure 6. Rear view of the 24 x 2.5-inch drive system

- | | |
|---|---|
| 1. Riser 1 - Full-height PCIe expansion card (Slot 1 and 2) | 2. Half-height PCIe expansion card slots located on the system board (Slot 3 and 4) |
| 3. Riser 2 - Full-height PCIe expansion card slots (Slot 5 and 6) | 4. Power supply units (2) |
| 5. System identification button | 6. iDRAC9 dedicated port |
| 7. USB 3.0 ports (2) | 8. VGA port |
| 9. Serial port | 10. NIC ports (4) |
| 11. Rear handle | |




Figure 7. Rear view of the 24 x 2.5-inch + 2 x 2.5-inch (rear) drive system

- | | |
|---|---|
| 1. Riser 1 - Full-height PCIe expansion card slots (Slot 1 and 2) | 2. Half-height PCIe expansion card slots located on the system board (Slot 3 and 4) |
| 3. Rear drives (2) | 4. Power supply units (2) |
| 5. System identification button | 6. iDRAC9 dedicated port |
| 7. USB 3.0 ports (2) | 8. VGA port |
| 9. Serial port | 10. NIC ports (4) |

11. Rear handle

For more information, see the Dell EMC PowerEdge R840 Technical Specifications on the product documentation page.

Inside the system

NOTE: Components that are hot swappable have orange touch points and the components that are not hot swappable have blue touch points.




Figure 8. Inside the system without rear drive cage

- | | |
|---------------------------------------|---------------------------------------|
| 1. Drive backplane | 2. SAS Expander board |
| 3. Cooling fans (6) | 4. System board |
| 5. Full-height expansion card Riser 2 | 6. Full-height expansion card Riser 1 |
| 7. Intrusion switch | |




Figure 9. Inside the system with rear drive cage


- | | |
|----------------------|---------------------------------------|
| 1. Drive backplane | 2. SAS Expander board |
| 3. Cooling fans (6) | 4. System board |
| 5. Drive cage (rear) | 6. Full-height expansion card Riser 1 |
| 7. Intrusion switch | |

Locating the Service Tag of your system

You can identify your system using the unique Express Service Code and Service Tag. Pull out the information tag in the front of the system to view the Express Service Code and Service Tag. Alternatively, the information may be on a sticker on the chassis of the system.

The mini Enterprise Service Tag (EST) is found on the back of the system. This information is used by Dell to route support calls to the appropriate personnel.

Figure 10. Locating Service Tag of your system



1. Information tag (top view)
2. Information tag (bottom view)
3. OpenManage Mobile (OMM) label (optional)
4. iDRAC MAC address and iDRAC secure password label

NOTE: If you have opted for secure default access to iDRAC, the iDRAC secure default password is available on the back of the system Information tag. This section of label will be blank, if you have not opted for secure default access to iDRAC, then the default user name and password are root and calvin.

5. Service Tag

System Information Label

PowerEdge R840 – Front system information label




Figure 11. LED behavior, and Configuration and Layout

PowerEdge R840 – Service information




Figure 12. Mechanical overview




Figure 13. Signal and power cable routing




Figure 14. Electrical overview




Figure 15. CPU installation




Figure 16. Express service tag

Initial system setup and configuration

Topics:

- [Setting up your system](#)
- [iDRAC configuration](#)
- [Options to install the operating system](#)

Setting up your system

Perform the following steps to set up your system:

Steps

1. Unpack the system.
2. Install the system into the rack. For more information about installing the system into the rack, see the *Rail Installation Guide* at www.dell.com/poweredgemanuals.
3. Connect the peripherals to the system.
4. Connect the system to its electrical outlet.
5. Power on the system by pressing the power button or by using iDRAC.
6. Power on the attached peripherals.

For more information about setting up your system, see the *Getting Started Guide* that shipped with your system.

For information on how to manage basic settings and features of the system, see the Dell EMC PowerEdge R840 BIOS and UEFI Reference Guide on the product documentation page.

iDRAC configuration

The Integrated Dell Remote Access Controller (iDRAC) is designed to make system administrators more productive and improve the overall availability of Dell systems. iDRAC alerts administrators about system issues and enables them to perform remote system management. This reduces the need for physical access to the system.

Options to set up iDRAC IP address

To enable communication between your system and iDRAC, you must first configure the network settings based on your network infrastructure.

 **NOTE:** For static IP configuration, you must request for it at the time of purchase.

This option is set to **DHCP** by Default. You can set up the IP address by using one of the following interfaces:

Interfaces	Document/Section
iDRAC Settings utility	<i>Dell Integrated Dell Remote Access Controller User's Guide</i> at www.dell.com/poweredgemanuals
Dell Deployment Toolkit	<i>Dell Deployment Toolkit User's Guide</i> at www.dell.com/openmanagemanuals > OpenManage Deployment Toolkit
Dell Lifecycle Controller	<i>Dell Lifecycle Controller User's Guide</i> at www.dell.com/poweredgemanuals
Server LCD panel	LCD panel section

Interfaces Document/Section

iDRAC Direct and Quick Sync 2 (optional) See *Dell Integrated Dell Remote Access Controller User's Guide* at www.dell.com/poweredgemanuals

NOTE: To access iDRAC, ensure that you connect the ethernet cable to the iDRAC9 dedicated network port. You can also access iDRAC through the shared LOM mode, if you have opted for a system that has the shared LOM mode enabled.

Log in to iDRAC

You can log in to iDRAC as:

- iDRAC user
- Microsoft Active Directory user
- Lightweight Directory Access Protocol (LDAP) user

If you have opted for secure default access to iDRAC, you must use the iDRAC secure default password available on the system Information tag. If you have not opted for secure default access to iDRAC, then use the default user name and password `-root` and `calvin`. You can also log in by using your Single Sign-On or Smart Card.

NOTE: You must have the iDRAC credentials to log in to iDRAC.

NOTE: Ensure that you change the default username and password after setting up the iDRAC IP address.

For more information about logging in to the iDRAC and iDRAC licenses, see the latest *Integrated Dell Remote Access Controller User's Guide* at www.dell.com/poweredgemanuals.

You can also access iDRAC by using RACADM. For more information, see the *RACADM Command Line Interface Reference Guide* at www.dell.com/poweredgemanuals.

Options to install the operating system

If the system is shipped without an operating system, install a supported operating system by using one of the following resources:

Table 2. Resources to install the operating system

Resources	Location
iDRAC	www.dell.com/idracmanuals
Lifecycle Controller	www.dell.com/idracmanuals > Lifecycle Controller
OpenManage Deployment Toolkit	www.dell.com/openmanagemanuals > OpenManage Deployment Toolkit
Dell certified VMware ESXi	www.dell.com/virtualizationsolutions
Installation and How-to videos for supported operating systems on PowerEdge systems	Supported Operating Systems for Dell EMC PowerEdge systems

Methods to download firmware and drivers

You can download the firmware and drivers by using any of the following methods:

Table 3. Firmware and drivers

Methods	Location
From the Dell EMC support site	www.dell.com/support/home
Using Dell Remote Access Controller Lifecycle Controller (iDRAC with LC)	www.dell.com/idracmanuals

Table 3. Firmware and drivers (continued)

Methods	Location
Using Dell Repository Manager (DRM)	www.dell.com/openmanagemanuals > Repository Manager
Using Dell OpenManage Essentials	www.dell.com/openmanagemanuals > OpenManage Essentials
Using Dell OpenManage Enterprise	www.dell.com/openmanagemanuals > OpenManage Enterprise
Using Dell Server Update Utility (SUU)	www.dell.com/openmanagemanuals > Server Update Utility
Using Dell OpenManage Deployment Toolkit (DTK)	www.dell.com/openmanagemanuals > OpenManage Deployment Toolkit
Using iDRAC virtual media	www.dell.com/idracmanuals

Downloading drivers and firmware

Dell EMC recommends that you download and install the latest BIOS, drivers, and systems management firmware on your system.

Prerequisites

Ensure that you clear the web browser cache before downloading the drivers and firmware.

Steps

1. Go to www.dell.com/support/home.
2. In the **Drivers & Downloads** section, type the Service Tag of your system in the **Enter a Service Tag or product ID** box, and then click **Submit**.
 **NOTE:** If you do not have the Service Tag, select **Detect Product** to allow the system to automatically detect the Service Tag, or click **View products**, and navigate to your product.
3. Click **Drivers & Downloads**.
The drivers that are applicable to your system are displayed.
4. Download the drivers to a USB drive, CD, or DVD.

Installing and removing system components

Topics:

- Safety instructions
- Before working inside your system
- After working inside your system
- Recommended tools
- Optional front bezel
- System cover
- Air shroud
- Cooling fan assembly
- Cooling fans
- NVDIMM-N battery
- Drives
- Rear drive cage
- System memory
- Expansion cards and expansion card risers
- Optional M.2 SSD module
- Processors and heat sinks
- Optional IDSDM or vFlash module
- Network daughter card
- Drive backplane
- Cable routing
- System battery
- Optional USB 3.0 module
- Optional internal USB memory key
- Optional optical drive
- Power supply units
- Power Interposer Board
- System board
- Restore the service tag using Easy Restore
- Trusted Platform Module
- Control panel

Safety instructions

 **NOTE:** Whenever you need to lift the system, get others to assist you. To avoid injury, do not attempt to lift the system by yourself.

 **WARNING:** Opening or removing the system cover while the system is powered on may expose you to a risk of electric shock.

 **CAUTION:** Do not operate the system without the cover for a duration exceeding five minutes. Operating the system without the system cover can result in component damage.

 **CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that are shipped with your product.

 **NOTE:** It is recommended that you always use an antistatic mat and antistatic strap while working on components inside the system.

 **CAUTION:** To ensure proper operation and cooling, all bays in the system and system fans must be always populated with a component or a blank.

 **CAUTION:** Ensure to have two or more people to lift the system horizontally from the box and place it on a flat surface, rack lift, or into the rails.

Before working inside your system

Prerequisites

Follow the safety guidelines listed in [Safety instructions](#).

Steps

1. Turn off the system, including all attached peripherals.
2. Disconnect the system from the electrical outlet and disconnect the peripherals.
3. If applicable, remove the system from the rack.
For more information, see the *Rail Installation Guide* at <https://www.dell.com/poweredgemanuals>.
4. [Remove the system cover](#).

After working inside your system

Prerequisites

Follow the safety guidelines listed in [Safety instructions](#).

Steps

1. [Install the system cover](#).
2. If applicable, install the system into the rack.
For more information, see the *Rail Installation Guide* at <https://www.dell.com/poweredgemanuals>.
3. Reconnect the peripherals and connect the system to the electrical outlet.
4. Turn on the attached peripherals and then turn on the system.

Recommended tools

You need the following tools to perform the removal and installation procedures:

- Key to the bezel lock
The key is required only if your system includes a bezel.
- Phillips #1 screwdriver
- Phillips #2 screwdriver
- Torx #T30 screwdriver
- 1/4 inch flat head screwdriver
- Wrist grounding strap

You need the following tools to assemble the cables for a DC power supply unit:

- AMP 90871-1 hand-crimping tool or equivalent
- Tyco Electronics 58433-3 or equivalent
- Wire-stripper pliers to remove insulation from size 10 AWG solid or stranded, insulated copper wire

 **NOTE:** Use alpha wire part number 3080 or equivalent (65/30 stranding).

Optional front bezel

A lock on the bezel is used to protect unauthorized access to the drives. The system status can be viewed on the bezel with the LCD panel. For more information, see the [LCD panel](#) section.

Removing front bezel

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).

Steps

1. Unlock the bezel by using the bezel key.
2. Press the release button, and pull the left end of the bezel.
3. Unhook the right end, and remove the bezel.



Figure 17. Removing optional front bezel

Next steps

1. [Replace the bezel](#).

Installing the front bezel

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Locate and remove the bezel key.
NOTE: The bezel key is part of the LCD bezel package.

Steps

1. Align and insert the right end of the bezel onto the system.

2. Press the release button and fit the left end of the bezel onto the system.
3. Lock the bezel by using the key.




Figure 18. Installing the optional front bezel

System cover

Removing the system cover

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Turn off the system, including all attached peripherals.
3. Disconnect the system from the electrical outlet and disconnect the peripherals.
4. If applicable, remove the system from the rack.

NOTE: For more information, see the *Rail Installation Guide* at <https://www.dell.com/poweredgemanuals>.

Steps

1. Use a 1/4 inch flat head or a Phillips #2 screwdriver to turn the latch release lock counterclockwise to the unlock position.
2. Open the latch till the system cover slides back.
3. Lift the cover away from the system.

Figure 19. Removing the system cover



Next steps

1. [Replace the system cover.](#)

Installing system cover

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Ensure that all internal cables are routed correctly and connected, and no tools or extra parts are left inside the system.

Steps

1. Align the tabs on the system cover with the guide slots on the system.
2. Close the system cover latch.
3. Using a 1/4 inch flat head or Phillips #2 screwdriver, rotate the latch release lock clockwise to the lock position.



Figure 20. Installing system cover

Next steps

1. Follow the procedure listed in [After working inside your system.](#)

Air shroud

The air shroud directs the airflow across the entire system and maintain uniform airflow in the system. Air shroud prevents the system from overheating and is used to maintain uniform airflow inside the system. The system supports two types of air shrouds:

- Non-GPU air shroud
- GPU air shroud

Removing the non-GPU air shroud

Prerequisites

CAUTION: Never operate your system with the air shroud removed. The system may get overheated quickly, resulting in shutdown of the system and loss of data.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. If installed, [remove the NVDIMM battery](#).

Steps

Hold the air shroud and lift it away from the system.




Figure 21. Removing the non-GPU air shroud

Next steps

1. [Replace the non-GPU air shroud](#).

Installing the non-GPU air shroud

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).

Steps

1. Align the tabs on the air shroud with the slots on the system.
2. Lower the air shroud into the system until it is firmly seated.




Figure 22. Installing the non-GPU air shroud

Next steps

1. If applicable, [install the NVDIMM battery](#).
2. Follow the procedure listed in [After working inside your system](#).

Removing the GPU air shroud

Prerequisites

CAUTION: Never operate your system with the air shroud removed. The system may get overheated quickly, resulting in shutdown of the system and loss of data.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).

Steps

1. Holding the air shroud cover at the blue touch point, lift the cover at an angle to disengage it from the air shroud, and then lift it away from the system.




Figure 23. Removing the GPU air shroud cover

2. If installed, [remove the NVDIMM-N battery](#).
3. [Remove the expansion card riser 1 and 2](#).
4. Hold the air shroud and lift it away from the system.




Figure 24. Removing the GPU air shroud

Next steps

1. [Replace the air shroud](#).

Installing the GPU air shroud

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).

Steps

1. Align the tabs on the air shroud with the slots on the system.




Figure 25. Installing the GPU air shroud

2. Lower the air shroud into the system until it is firmly seated.
3. [Install the expansion card riser 1 and 2.](#)
4. If applicable, [install the NVDIMM-N battery.](#)
5. Holding the blue touch point on the air shroud cover, incline the cover at an angle, and then push it down until it is firmly seated.




Figure 26. Installing the GPU air shroud cover

Next steps

1. Follow the procedure listed in [After working inside your system.](#)

Cooling fan assembly

The cooling fan assembly ensures that the key components of the server such as the processors, drives, and memory get adequate air circulation to keep them cool. A failure in the server's cooling system can result in the server overheating and may lead to damage.

Removing the cooling fan assembly

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)

Steps

1. Lift the release levers to unlock the cooling fan assembly.
2. Holding the release levers, lift the cooling fan assembly out of the system.




Figure 27. Removing the cooling fan assembly

Next steps

1. [Replace the cooling fan assembly.](#)

Installing the cooling fan assembly

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).

Steps

1. Align the guide slots on the cooling fan assembly with the standoffs on the system.
2. Lower the cooling fan assembly into the system until the cooling fan connectors engage with the connectors on the system board.
3. Press the release levers to lock the cooling fan assembly in place.



Figure 28. Installing the cooling fan assembly

Next steps

1. Follow the procedure listed in [After working inside your system.](#)

Cooling fans

The cooling fans are integrated into the system to dissipate the heat generated by the functioning of the system. These fans provide cooling for the processors, expansion cards, and memory modules.

NOTE: Each fan is listed in the systems management software, referenced by the respective fan number. If there is a problem with a particular fan, you can easily identify and replace the proper fan by noting the fan numbers on the cooling fan assembly.

Removing a cooling fan

Prerequisites

NOTE: Opening or removing the system cover when the system is on may expose you to a risk of electric shock. Exercise utmost care while removing or installing cooling fans.

CAUTION: The cooling fans are hot swappable. To maintain proper cooling while the system is on, replace only one fan at a time.

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove the non-GPU air shroud](#) or [GPU air shroud.](#)

Steps

Press the release tab and lift the cooling fan out of the cooling fan assembly.




Figure 29. Removing cooling fan

Next steps

1. [Replace the cooling fan.](#)

Installing a cooling fan

Prerequisites

NOTE: Opening or removing the system cover when the system is on may expose you to a risk of electric shock. Exercise utmost care while removing or installing cooling fans.

CAUTION: The cooling fans are hot swappable. To maintain proper cooling while the system is on, replace only one fan at a time.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the non-GPU air shroud](#) or [GPU air shroud](#).

Steps

1. Holding the touch points on the cooling fan, align the connector on the cooling fan with the connector on the system board.
2. Slide the cooling fan into the cooling fan assembly until the release tab locks into place.




Figure 30. Installing cooling fan

Next steps

1. Install the [non-GPU air shroud](#) or [GPU air shroud](#).
2. Follow the procedure listed in [After working inside your system](#).

NVDIMM-N battery

The NVDIMM-N battery is installed on the air shroud.

Removing the NVDIMM-N battery

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. For GPU air shroud, [remove the GPU air shroud cover](#).

CAUTION: NVDIMM-N battery is not hot swappable. To prevent data loss and potential damage to your system, ensure that your system, LEDs on system, LEDs on NVDIMM-N and LEDs on NVDIMM-N battery are turned off, by disconnecting the cables, before removing the NVDIMM-N battery.

NOTE: To avoid damage to the battery connector, hold the connector while installing or removing a battery.

Steps

1. Disconnect the cables from the NVDIMM-N battery.
2. Using Phillips #2 screwdriver, loosen the screw securing the NVDIMM-N battery to the air shroud.
3. Holding the blue touch point, lift the NVDIMM-N battery at an angle to disengage it from the slot on the air shroud.
4. Lift the NVDIMM-N battery away from the system.




Figure 31. Removing the NVDIMM-N battery from the non-GPU air shroud




Figure 32. Removing the NVDIMM-N battery from the GPU air shroud

Next steps

1. [Replace the NVDIMM-N battery.](#)

Installing NVDIMM-N battery

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#)
3. For GPU air shroud, [remove the GPU air shroud cover](#).

CAUTION: NVDIMM-N battery is not hot swappable. To prevent data loss and potential damage to your system, ensure that your system, LEDs on system, LEDs on NVDIMM-N and LEDs on NVDIMM-N battery are turned off, by disconnecting the cables, before installing the NVDIMM-N battery.

CAUTION: To avoid damage to the battery connector, you must firmly support the connector while installing or removing a battery.

Steps

1. Incline the NVDIMM-N battery at an angle, and place the battery on the slot on the air shroud.
2. Using a Phillips #2 screwdriver, replace the screw to secure the NVDIMM-N battery to the air shroud.
3. Connect the cables to the NVDIMM-N battery.




Figure 33. Installing NVDIMM-N battery into non-GPU air shroud




Figure 34. Installing NVDIMM-N battery into GPU air shroud

Next steps

1. For GPU air shroud, [install the GPU air shroud cover](#).
2. Follow the procedure listed in [After working inside your system](#).

Drives

Removing a drive blank

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. If installed, [remove the front bezel](#).

CAUTION: To maintain proper system cooling, drive blanks must be installed in all empty drive slots.

CAUTION: Mixing drive blanks from previous generations of PowerEdge servers is not supported.

Steps

Press the release button, and slide the drive blank out of the drive slot.




Figure 35. Removing a drive blank

Next steps

1. [Install a drive or drive blank.](#)

Installing a drive blank

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. If installed, [remove the front bezel](#).

CAUTION: To maintain proper system cooling, drive blanks must be installed in all empty drive slots.

CAUTION: Mixing drive blanks from previous generations of PowerEdge servers is not supported.

Steps

Slide the drive blank into the drive slot until the release button clicks into place.




Figure 36. Installing a drive blank

Next steps

1. [Install the front bezel](#), if applicable.
2. Follow the procedure listed in [After working inside your system](#).

Removing a drive carrier

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).

2. Follow the procedure listed in [Before working inside your system](#).
3. If installed, [remove the front bezel](#).
4. Using the management software, prepare the drive for removal.

If the drive is online, the green activity or fault indicator flashes while the drive is turning off. When the drive indicators are off, the drive is ready for removal. For more information, see the storage controller documentation.

CAUTION: Before attempting to remove or install a drive while the system is running, see the documentation for the storage controller card to ensure that the host adapter is configured correctly to support drive removal and insertion.

CAUTION: Mixing drive carriers from previous generations of PowerEdge servers is not supported.

CAUTION: To prevent data loss, ensure that your operating system supports drive installation. See the documentation supplied with your operating system.

Steps

1. Press the release button to open the drive carrier release handle.
2. Holding the handle, slide the drive carrier out of the drive slot.

NOTE: If you are not replacing the drive immediately, install a drive blank in the empty drive slot to maintain proper system cooling.



Figure 37. Removing a drive carrier

Next steps

1. [Install a drive carrier](#) or [drive blank](#).

Installing a drive carrier

Prerequisites

CAUTION: Before attempting to remove or install a drive while the system is running, see the documentation for the storage controller card to ensure that the host adapter is configured correctly to support drive removal and insertion.

CAUTION: Combining SAS and SATA drives in the same RAID volume is not supported.

- ⚠ **CAUTION:** When installing a drive, ensure that the adjacent drives are fully installed. Inserting a drive carrier and attempting to lock its handle next to a partially installed carrier can damage the partially installed carrier's shield spring and make it unusable.
- ⚠ **CAUTION:** To prevent data loss, ensure that your operating system supports hot-swap drive installation. See the documentation supplied with your operating system.
- ⚠ **CAUTION:** When a replacement hot swappable drive is installed and the system is powered on, the drive automatically begins to rebuild. Ensure that the replacement drive is blank or contains data that you wish to overwrite. Any data on the replacement drive is immediately lost after the drive is installed.
1. Follow the safety guidelines listed in [Safety instructions](#).
 2. Follow the procedure listed in [Before working inside your system](#).
 3. If installed, [remove the front bezel](#).
 4. If installed, [remove the drive blank](#).

Steps

1. Press the release button on the front of the drive carrier to open the release handle.
2. Insert the drive carrier into the drive slot and push the drive until it connects with the backplane.
3. Close the drive carrier release handle to lock the drive in place.



Figure 38. Installing a drive carrier

Next steps

1. If applicable, [install the front bezel](#).
2. Follow the procedure listed in [After working inside your system](#).

Removing the drive from the drive carrier

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
⚠ **CAUTION:** Mixing drive carriers from previous generations of PowerEdge servers is not supported.
2. Follow the procedure listed in [Before working inside your system](#).
3. If installed, [remove the front bezel](#).
4. [Remove the drive carrier](#).

Steps

1. Using a Phillips #1 screwdriver, remove the screws from the slide rails on the drive carrier.
NOTE: If the 2.5-inch drive has Torx screw, use Torx 6 screwdriver to remove the drive from a 3.5-inch drive adapter. 
2. Lift the drive out of the drive carrier.



Figure 39. Removing the drive from the drive carrier

Next steps

1. [Install the drive into the drive carrier.](#)

Installing a drive into the drive carrier

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. If installed, [remove the front bezel](#).
4. [Remove the drive carrier](#).

 **CAUTION:** Mixing drive carriers from other generations of PowerEdge servers is not supported.

Steps

1. Insert the drive into the drive carrier with the connector end of the drive towards the back of the carrier.
2. Align the screw holes on the drive with the screws holes on the drive carrier.
When aligned correctly, the back of the drive is flush with the back of the drive carrier.
3. Using a Phillips #1 screwdriver, secure the drive to the drive carrier with screws.

NOTE: If the 2.5-inch drive has Torx screw, use Torx 6 screwdriver to install the drive to a 3.5-inch drive adapter. 

NOTE: When installing a drive into the drive carrier, ensure that the screws are torqued to 4 in-lbs.



Figure 40. Installing a drive into the drive carrier

Next steps

1. [Install the drive carrier.](#)
2. If applicable, [install the front bezel.](#)
3. Follow the procedure listed in [After working inside your system.](#)

Rear drive cage

The rear drive cage supports up to two 2.5 inch drives.

Removing the rear drive cage

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove the air shroud.](#)
4. [Remove all the drives.](#)
5. Disconnect all the cables from the rear drive backplane.

Steps

1. Using a Phillips #2 screwdriver, loosen the screws that secure the drive cage to the system.
2. Hold the drive cage and lift it away from the system.




Figure 41. Removing the rear drive cage

Next steps

1. [Replace the rear drive cage.](#)

Installing the rear drive cage

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).

Steps

1. Align the slots on drive cage with the guides on the system chassis.
2. Lower the drive cage into the system until it is firmly seated.
3. Using a Phillips #2 screwdriver, tighten the screws.




Figure 42. Installing the rear drive cage

Next steps

1. Connect all the cables to the rear drive backplane.
2. [Install the drives.](#)
3. [Install the air shroud.](#)
4. Follow the procedure listed in [After working inside your system.](#)

System memory

Your system contains 48 memory sockets split into four sets of 12 sockets, one set per processor. Each 12-socket set is organized into six channels. Six memory channels are allocated to each processor. In each channel, the release tabs of the first socket are marked white, and the second socket black.




Figure 43. Memory socket locations

Memory channels are organized as follows:

Table 4. Memory channels

Processor	Channel 0	Channel 1	Channel 2	Channel 3	Channel 4	Channel 5
Processor 1	Slots A1 and A7	Slots A2 and A8	Slots A3 and A9	Slots A4 and A10	Slots A5 and A11	Slots A6 and A12
Processor 2	Slots B1 and B7	Slots B2 and B8	Slots B3 and B9	Slots B4 and B10	Slots B5 and B11	Slots B6 and B12
Processor 3	Slots C1 and C7	Slots C2 and C8	Slots C3 and C9	Slots C4 and C10	Slots C5 and C11	Slots C6 and C12
Processor 4	Slots D1 and D7	Slots D2 and D8	Slots D3 and D9	Slots D4 and D10	Slots D5 and D11	Slots D6 and D12

General memory module installation guidelines

To ensure optimal performance of your system, observe the following general guidelines when configuring your system memory. If your system's memory configurations fail to observe these guidelines, your system might not boot, stop responding during memory configuration, or operate with reduced memory.

The memory bus may operate at frequencies 2933 MT/s, 2666 MT/s, 2400 MT/s, or 2133 MT/s depending on the following factors:

- System profile selected (for example, Performance Optimized, or Custom [can be run at high speed or lower])
- Maximum supported DIMM speed of the processors. For memory frequency of 2933 MT/s, one DIMM per channel is supported.
- Maximum supported DIMM speed of the processors.
- Maximum supported speed of the DIMMs

 **NOTE:** MT/s indicates DIMM speed in MegaTransfers per second.

The system supports Flexible Memory Configuration, enabling the system to be configured and run in any valid chipset architectural configuration. The following are the recommended guidelines for installing memory modules:

- All DIMMs must be DDR4.
 - RDIMMs and LRDIMMs must not be mixed.
 - NVDIMMs and LRDIMMs must not be mixed.
 - NVDIMMs and RDIMMs can be mixed.
 - 64 GB LRDIMMs that are DDP (Dual Die Package) LRDIMMs must not be mixed with 128 GB LRDIMMs that are TSV (Through Silicon Via/3DS) LRDIMMs.
 - x4 and x8 DRAM based memory modules can be mixed.
 - Up to two RDIMMs can be populated per channel regardless of rank count.
 - Up to two LRDIMMs can be populated per channel regardless of rank count.
 - 256 GB LRDIMMs only support 8x 2.5" Chassis at 30°C ambient temperature.
 - 256 GB does not support GPU configuration.
 - A maximum of two different ranked DIMMs can be populated in a channel regardless of rank count.
 - If memory modules with different speeds are installed, they will operate at the speed of the slowest installed memory module(s).
 - Populate memory module sockets only if a processor is installed.
 - For single-processor systems, sockets A1 to A12 are available.
 - For dual-processor systems, sockets A1 to A12 and sockets B1 to B12 are available.
 - For quad-processor systems, sockets A1 to A12, sockets B1 to B12, sockets C1 to C12, and sockets D1 to D12 are available.
 - Populate all the sockets with white release tabs first, followed by the black release tabs.
 - When mixing memory modules with different capacities, populate the sockets with memory modules with the highest capacity first.
-  **NOTE:** For example, if you want to mix 8 GB and 16 GB memory modules, populate 16 GB memory modules in the sockets with white release tabs and 8 GB memory modules in the sockets with black release tabs.
- Memory modules of different capacities can be mixed provided other memory population rules are followed.

 **NOTE:** For example, 8 GB and 16 GB memory modules can be mixed.

- In a dual-processor configuration, the memory configuration for each processor must be identical.

 **NOTE:** For example, if you populate socket A1 for processor 1, then populate socket B1 for processor 2, and so on.

- Mixing of more than two memory module capacities in one system is not supported.
- Unbalanced memory configurations will result in a performance loss so always populate memory channels identically with identical DIMMs for best performance.
- Populate six identical memory modules per processor (one DIMM per channel) at a time to maximize performance.

DIMM population update for Performance Optimized mode with quantity of 4 and 8 DIMMs per processor.

- When the DIMM quantity is 4 per processor, the population is slot 1, 2, 4, 5.
- When the DIMM quantity is 8 per processor, the population is slot 1, 2, 4, 5, 7, 8, 10, 11.

NVDIMM-N memory module installation guidelines

The following are the recommended guidelines for installing NVDIMM-N memory modules:

- Each system supports memory configurations with 1, 2, 4, 6, or 12 NVDIMM-Ns.
- Supported configurations have dual processors and a minimum of 12x RDIMMs.
- Maximum of 12 NVDIMM-Ns can be installed in a system.
- NVDIMM-Ns or RDIMMs must not be mixed with LRDIMMs.
- DDR4 NVDIMM-Ns must be populated only on the black release tabs on processor 1 and 2.
- For systems with four processors, RDIMMs populated on processor 3 and 4 must be identical to the number of RDIMMs populated on processor 1 and 2.
- All slots on configurations 3, 6, 9, and 12 can be used, but a maximum of 12 NVDIMM-Ns can be installed in a system.

 **NOTE:** NVDIMM-N memory slots are not hot-pluggable.

For more information about the supported NVDIMM-N configurations, see the *NVDIMM-N User Guide* at www.dell.com/poweredgemanuals.

Table 5. Supported NVDIMM-N for dual processor configurations

Configuration	Description	Memory population rules	
		RDIMMs	NVDIMM-N
Configuration 1	12x 16 GB RDIMMs, 1x NVDIMM-N	Processor1 {A1, 2, 3, 4, 5, 6} Processor2 {B1, 2, 3, 4, 5, 6}	Processor1 {A7}
Configuration 2	12x 32 GB RDIMMs, 1x NVDIMM-N	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7}
Configuration 3	23x 32 GB RDIMMs, 1x NVDIMM-N	Processor1 {A1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12} Processor2 {B1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11}	Processor2 {B12}
Configuration 4	12x 16 GB RDIMMs, 2x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7} Processor2 {B7}
Configuration 5	12x 32 GB RDIMMs, 2x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7} Processor2 {B7}
Configuration 6	22x 32 GB RDIMMs, 2x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11} Processor2 {B1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11}	Processor1 {A12} Processor2 {B12}
Configuration 7	12x 16 GB RDIMMs, 4x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7, A8} Processor2 {B7, B8}
Configuration 8	22x 32 GB RDIMMs, 4x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7, A8} Processor2 {B7, B8}
Configuration 9	20x 32 GB RDIMMs, 4x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6, 7, 8, 9, 10} Processor2 {B1, 2, 3, 4, 5, 6, 7, 8, 9, 10}	Processor1 {A11, 12} Processor2 {B11, 12}

Table 5. Supported NVDIMM-N for dual processor configurations (continued)

Configuration	Description	Memory population rules	
		RDIMMs	NVDIMM-N
Configuration 10	12x 16 GB RDIMMs, 6x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7, 8, 9} Processor2 {B7, 8, 9}
Configuration 11	12x 32 GB RDIMMs, 6x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7, 8, 9} Processor2 {B7, 8, 9}
Configuration 12	18x 32 GB RDIMMs, 6x NVDIMM-Ns	Processor1 {1, 2, 3, 4, 5, 6, 7, 8, 9} Processor2 {1, 2, 3, 4, 5, 6, 7, 8, 9}	Processor1 {A10, 11, 12} Processor2 {B10, 11, 12}
Configuration 13	12x 16 GB RDIMMs, 12x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7, 8, 9, 10, 11, 12} Processor2 {B7, 8, 9, 10, 11, 12}
Configuration 14	12x 32 GB RDIMMs, 12x NVDIMM-Ns	Same for all 12x RDIMM configurations. See Configuration 1.	Processor1 {A7, 8, 9, 10, 11, 12} Processor2 {B7, 8, 9, 10, 11, 12}

Table 6. Supported NVDIMM-N for quad processor configurations

Configuration	Description	Memory population rules	
		RDIMMs	NVDIMM-N
Configuration 1	24x 16 GB RDIMMs, 1x NVDIMM-N	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6}, Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7}
Configuration 2	24x 32 GB RDIMMs, 1x NVDIMM-N	Same for all 24x RDIMM configurations. See Configuration 1.	Processor1 {A7}
Configuration 3	47x 32 GB RDIMMs, 1x NVDIMM-N	Processor1 {A1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12} , Processor2 {B1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11} , Processor3 {C1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12} Processor 4 {D1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12}	Processor2 {B12}
Configuration 4	24x 16 GB RDIMMs, 2x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6} Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7}, Processor2 {B7}
Configuration 5	24x 32 GB RDIMMs, 2x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6}, Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7}, Processor2 {B7}

Table 6. Supported NVDIMM-N for quad processor configurations (continued)

Configuration	Description	Memory population rules	
		RDIMMs	NVDIMM-N
Configuration 6	46x 32 GB RDIMMs, 2x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11}, Processor2 {B1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11} , Processor3 {C1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12} Processor 4 {D1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12}	Processor1 {A12}, Processor2 {B12}
Configuration 7	24x 16 GB RDIMMs, 4x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6}, Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7,8}, Processor2 {B7,8}
Configuration 8	24x 32 GB RDIMMs, 4x NVDIMMs	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6}, Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7,8}, Processor2 {B7,8}
Configuration 9	44x 32 GB RDIMMs, 4x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6, 7, 8, 9, 10}, Processor2 {B1, 2, 3, 4, 5, 6, 7, 8, 9, 10}, Processor3 {C1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12} Processor4 {D1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12}	Processor1 {A11, 12}, Processor2 {B11, 12}
Configuration 10	24x 16 GB RDIMMs, 6x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6} Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7, 8, 9} Processor2 {B7, 8, 9}
Configuration 11	24x 32 GB RDIMMs, 6x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6}, Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7, 8, 9} Processor2 {B7, 8, 9}
Configuration 12	42x 32 GB RDIMMs, 6x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6, 7, 8, 9}, Processor2 {B1, 2, 3, 4, 5, 6, 7, 8, 9} Processor3 {C1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12} Processor4 {D1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12}	Processor1 {A10,11,12} Processor2 {B10, 11, 12}
Configuration 13	24x 16 GB RDIMMs, 12x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6}, Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor1 {A7, 8, 9, 10, 11, 12}, Processor2 {B7, 8, 9, 10, 11, 12}
Configuration 14	24x 32 GB RDIMMs, 12x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6},	Processor1 {A7, 8, 9, 10, 11, 12},

Table 6. Supported NVDIMM-N for quad processor configurations (continued)

Configuration	Description	Memory population rules	
		RDIMMs	NVDIMM-N
		Processor3 {C1, 2, 3, 4, 5, 6} Processor4 {D1, 2, 3, 4, 5, 6}	Processor2 {B7, 8, 9, 10, 11, 12}
Configuration 15	36x 32 GB RDIMMs, 12x NVDIMM-Ns	Processor1 {A1, 2, 3, 4, 5, 6}, Processor2 {B1, 2, 3, 4, 5, 6}, Processor3 {C1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12} Processor 4 {D1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12}	Processor1 {A7, 8, 9, 10, 11, 12}, Processor2 {B7, 8, 9, 10, 11, 12}

PMem installation guidelines

The following are the recommended guidelines for installing data center persistent memory module (PMem) memory modules:

- Each system supports maximum of one PMem memory module per channel.
- i NOTE:** If two different PMem capacities are mixed, an F1/F2 warning is displayed as the configuration is not supported.
- PMem can be mixed with RDIMM, LRDIMM, and 3DS LRDIMM.
- Mixing of DDR4 DIMM types (RDIMM, LRDIMM, and 3DS LRDIMM), within channels, for Integrated Memory Controller (iMC), or across sockets are not supported.
- Mixing of PMem operating modes (App Direct, Memory Mode) is not supported.
- If only one DIMM is populated on a channel, it should always go to the first slot in that channel (white slot).
- If a PMem and a DDR4 DIMM are populated on the same channel, always plug PMem on second slot (black slot).
- If the PMem is configured in Memory Mode, the recommended DDR4 to PMem capacity ratio is 1:4 to 1:16 per iMC.
- PMems' cannot be mixed with other PMems capacities or NVDIMMs.
- Mixing different capacities of RDIMMs and LRDIMMs are not allowed when PMem is installed.
- PMems of different capacities are not allowed.
- PMem does not support GPU configurations

For more information about the supported PMem configurations, see the *Dell EMC PMem User 's Guide* at https://www.dell.com/support/home/products/server_int/server_int_poweredge.

Table 7. 2 socket PMem configurations

No. of CPUs in the Server	PMem Population	DRAM Population	DRAM Capacity (GB)	PMem Capacity (GB)	Operating system Memory in Memory Mode (GB)	Total Memory (GB)	Total Memory per CPU (GB)	Ratio DRAM to Optane Memory	Requires an M or L CPU	Supported in App Direct Mode	Supported in Memory Mode
2	128 GB x 1	16 GB x 12	192	128	N/A	320	160	1 : 0.7	No	Yes	No
2	128 GB x 2	16 GB x 12	192	256	N/A	448	224	1 : 1.3	No	Yes	No
2	128 GB x 4	16 GB x 8	128	512	512	640	320	1 : 4	No	Yes	Yes
2	128 GB x 4	16 GB x 12	192	512	N/A	704	352	1 : 2.7	No	Yes	No
2	128 GB x 8	16 GB x 12	192	1,024	1,024	1,216	608	1 : 5.3	No	Yes	Yes
2	128 GB x 12	16 GB x 12	192	1,536	1,536	1,728	864	1 : 8	No	Yes	Yes
2	128 GB x 1	32 GB x 12	384	128	N/A	512	256	1 : 0.3	No	Yes	No

Table 7. 2 socket PMem configurations (continued)

No. of CPUs in the Server	PMem Population	DRAM Population	DRAM Capacity (GB)	PMem Capacity (GB)	Operating system Memory in Memory Mode (GB)	Total Memory (GB)	Total Memory per CPU (GB)	Ratio DRAM to Optane Memory	Requires an M or L CPU	Supported in App Direct Mode	Supported in Memory Mode
2	128 GB x 2	32 GB x 12	384	256	N/A	640	320	1 : 0.7	No	Yes	No
2	128 GB x 4	32 GB x 12	384	512	N/A	896	448	1 : 1.3	No	Yes	No
2	128 GB x 8	32 GB x 12	384	1,024	N/A	1,408	704	1 : 2.7	No	Yes	No
2	128 GB x 12	32 GB x 12	384	1,536	1,536	1,920	960	1 : 4	No	Yes	Yes
2	128 GB x 4	64 GB x 12	768	512	N/A	1,280	640	1 : 0.7	No	Yes	No
2	128 GB x 8	64 GB x 12	768	1,024	N/A	1,792	896	1 : 1.3	No	Yes	No
2	128 GB x 12	64 GB x 12	768	1,536	N/A	2,304	1,152	1 : 2	L SKU	Yes	No
2	128 GB x 12	128 GB x 12	1,536	1,536	N/A	3,072	1,536	1 : 1	L SKU	Yes	No
2	512 GB x 8	32 GB x 12	384	4,096	4,096	4,480	2,240	1 : 10.7	L SKU	Yes	Yes
2	512 GB x 12	32 GB x 12	384	6,144	6,144	6,528	3,264	1 : 16	L SKU	Yes	Yes
2	512 GB x 8	64 GB x 12	768	4,096	4,096	4,864	2,432	1 : 5.3	L SKU	Yes	Yes
2	512 GB x 12	64 GB x 12	768	6,144	6,144	6,912	3,456	1 : 8	L SKU	Yes	Yes
2	512 GB x 12	128 GB x 12	1,536	6,144	6,144	7,680	3,840	1 : 4	L SKU	Yes	Yes
2	256 GB x 8	16 GB x 12	192	2,048	2,048	2,240	1,120	1 : 10.7	L SKU	Yes	Yes
2	256 GB x 8	32 GB x 12	384	2,048	2,048	2,432	1,216	1 : 5.3	L SKU	Yes	Yes
2	256 GB x 12	32 GB x 12	384	3,072	3,072	3,456	1,728	1 : 8	L SKU	Yes	Yes
2	256 GB x 8	64 GB x 12	768	2,048	N/A	2,816	1,408	1 : 2.7	L SKU	Yes	No
2	256 GB x 12	64 GB x 12	768	3,072	3,072	3,840	1,920	1 : 4	L SKU	Yes	Yes
2	256 GB x 12	128 GB x 12	1,536	3,072	N/A	4,608	2,304	1 : 2	L SKU	Yes	No

Table 8. 4 socket PMem configurations

No. of CPUs in the Server	PMem Populatio	DRAM Populatio	DRAM Capacity (GB)	PMem Capacity (GB)	Operating system Memory in Memory Mode (GB)	Total Memory (GB)	Total Memory per CPU (GB)	Ratio DRAM to Optane Memory	Requires an M or L CPU	Supported in App Direct Mode	Supported in Memory Mode
4	128 GB x 16	16 GB x 24	384	2,048	2,048	2,432	608	1 : 5.3	No	Yes	Yes
4	128 GB x 24	16 GB x 24	384	3,072	3,072	3,456	864	1 : 8	No	Yes	Yes
4	128 GB x 16	32 GB x 24	768	2,048	N/A	2,816	704	1 : 2.7	No	Yes	No
4	128 GB x 24	32 GB x 24	768	3,072	3,072	3,840	960	1 : 4	No	Yes	Yes
4	128 GB x 24	64 GB x 24	1,536	3,072	N/A	4,608	1,152	1 : 2	L SKU	Yes	No
4	128 GB x 24	128 GB x 24	3,072	3,072	N/A	6,144	1,536	1 : 1	L SKU	Yes	No
4	512 GB x 16	32 GB x 24	768	8,192	8,192	8,960	2,240	1 : 10.7	L SKU	Yes	Yes
4	512 GB x 24	32 GB x 24	768	12,288	12,288	13,056	3,264	1 : 16	L SKU	Yes	Yes
4	512 GB x 16	64 GB x 24	1,536	8,192	8,192	9,728	2,432	1 : 5.3	L SKU	Yes	Yes
4	512 GB x 24	64 GB x 24	1,536	12,288	12,288	13,824	3,456	1 : 8	L SKU	Yes	Yes
4	512 GB x 24	128 GB x 24	3,072	12,288	12,288	15,360	3,840	1 : 4	L SKU	Yes	Yes
4	256 GB x 16	16 GB x 24	384	4,096	4,096	4,480	1,120	1 : 10.7	L SKU	Yes	Yes
4	256 GB x 24	16 GB x 24	384	6,144	6,144	6,528	1,632	1 : 16	L SKU	Yes	Yes
4	256 GB x 16	32 GB x 24	768	4,096	4,096	4,864	1,216	1 : 5.3	L SKU	Yes	Yes
4	256 GB x 24	32 GB x 24	768	6,144	6,144	6,912	1,728	1 : 8	L SKU	Yes	Yes
4	256 GB x 16	64 GB x 24	1,536	4,096	N/A	5,632	1,408	1 : 2.7	L SKU	Yes	No
4	256 GB x 24	64 GB x 24	1,536	6,144	6,144	7,680	1,920	1 : 4	L SKU	Yes	Yes
4	256 GB x 24	128 GB x 24	3,072	6,144	N/A	9,216	2,304	1 : 2	L SKU	Yes	No

NOTE:

PMem is supported on systems with 1600W and 2400W PSU configuration.

Max ambient Temperature is 30C.

Max hard drive is 2.5-inches x 8.

PMem does not support GPU configuration.

PMem does not support NVMe hard drive.

Table 9. PMem Thermal Restrictions

PMem Support	V2 Air-shroud	V1 Air-shroud
8x 2.5-inch SAS/SATA	35C ambient temperature support, 30C ambient temperature with 256GB LRDIMMs	30C ambient temperature support, not supported with 256GB LRDIMMs
8x 2.5-inch NVMe	35C ambient temperature support, 30C ambient temperature with 256GB LRDIMMs	Not supported
24x 2.5-inch SAS/SATA or NVMe	30C ambient temperature support, not supported with 256GB LRDIMMs	Not supported

 **NOTE:** PMem does not support GPU configuration.

Mode-specific guidelines

The configurations allowed depend on the memory mode selected in the System BIOS.

Table 10. Memory operating modes

Memory Operating Mode	Description
Optimizer Mode	The Optimizer Mode if enabled, the DRAM controllers operate independently in the 64-bit mode and provide optimized memory performance.  NOTE: PMem supports only Optimizer mode.
Mirror Mode	The Mirror Mode if enabled, the system maintains two identical copies of data in memory, and the total available system memory is one half of the total installed physical memory. Half of the installed memory is used to mirror the active memory modules. This feature provides maximum reliability and enables the system to continue running even during a catastrophic memory failure by switching over to the mirrored copy. The installation guidelines to enable Mirror Mode require that the memory modules be identical in size, speed, and technology, and they must be populated in sets of 6 per processor.
Single Rank Spare Mode	Single Rank Spare Mode allocates one rank per channel as a spare. If excessive correctable errors occur in a rank or channel, while the operating system is running, they are moved to the spare area to prevent errors from causing an uncorrectable failure. Requires two or more ranks to be populated in each channel.
Multi Rank Spare Mode	Multi Rank Spare Mode allocates two ranks per channel as a spare. If excessive correctable errors occur in a rank or channel, while the operating system is running, they are moved to the spare area to prevent errors from causing an uncorrectable failure. Requires three or more ranks to be populated in each channel. With single rank memory sparing enabled, the system memory available to the operating system is reduced by one rank per channel. For example, in a dual-processor configuration with 24x 16 GB dual-rank memory modules, the available system memory is: $\frac{3}{4} (\text{ranks/channel}) \times 24 (\text{memory modules}) \times 16 \text{ GB} = 288 \text{ GB}$, and not $24 (\text{memory modules}) \times 16 \text{ GB} = 384 \text{ GB}$. For multi rank sparing, the multiplier changes to $\frac{1}{2} (\text{ranks/channel})$.

Table 10. Memory operating modes (continued)

Memory Operating Mode	Description
	 NOTE: To use memory sparing, this feature must be enabled in the BIOS menu of System Setup.  NOTE: Memory sparing does not offer protection against a multi-bit uncorrectable error.
Dell Fault Resilient Mode	The Dell Fault Resilient Mode if enabled, the BIOS creates an area of memory that is fault resilient. This mode can be used by an OS that supports the feature to load critical applications or enables the OS kernel to maximize system availability.  NOTE: This feature is only supported in Gold and Platinum Intel processors.  NOTE: Memory configuration has to be of same size DIMM, speed, and rank.

Optimizer Mode

This mode supports Single Device Data Correction (SDDC) only for memory modules that use x4 device width. It does not impose any specific slot population requirements.

- Dual processor: Populate the slots in round robin sequence starting with processor 1.
 **NOTE:** Processor 1 and processor 2 population should match.
- Quad processor: Populate the slots in round robin sequence starting with processor 1.
 **NOTE:** Processor 1, processor 2, processor 3, and processor 4 population should match.

Table 11. Memory population rules

Processor	Configuration	Memory population	Memory population information
Dual processor (Start with processor1. processor1 and processor 2 population should match)	Optimized (Independent channel) population order	A{1}, B{1}, A{2}, B{2}, A{3}, B{3}, A{4}, B{4}, A{5}, B{5}, A{6}, B{6}	Odd number of DIMM population per processor is allowed.  NOTE: Odd number of DIMMs will result in unbalanced memory configurations, which in turn will result in performance loss. It is recommended to populate all memory channels identically with identical DIMMs for best performance.  NOTE: For best performance, 6 DIMMs or 12 DIMMs per processor is recommended. Optimizer population order is not traditional for 8 and 16 DIMMs installations for dual processor. • For 8 DIMMs: A1, A2, A4, A5, B1, B2, B4, B5 • For 16 DIMMs: A1, A2, A4, A5, A7, A8, A10, A11 B1, B2, B4, B5, B7, B8, B10, B11
	Mirroring population order	A{1, 2, 3, 4, 5, 6}, B{1, 2, 3, 4, 5, 6}, A{7, 8, 9, 10, 11, 12}, B{7, 8, 9, 10, 11, 12}	Mirroring is supported with 6 or 12 DIMMs per processor.
	Single rank sparing population order	A{1}, B{1}, A{2}, B{2}, A{3}, B{3}, A{4}, B{4}, A{5}, B{5}, A{6}, B{6}	• DIMMs must be populated in the order specified. • Requires two ranks or more per channel.

Table 11. Memory population rules (continued)

Processor	Configuration	Memory population	Memory population information
	Multi rank sparing population order	A{1}, B{1}, A{2}, B{2}, A{3}, B{3}, A{4}, B{4}, A{5}, B{5}, A{6}, B{6}	- DIMMs must be populated in the order specified. - Requires three ranks or more per channel.
	Fault resilient population order	A{1, 2, 3, 4, 5, 6}, B{1, 2, 3, 4, 5, 6}, A{7, 8, 9, 10, 11, 12}, B{7, 8, 9, 10, 11, 12}	Supported with 6 or 12 DIMMs per processor.
Quad processor (Starting with processor 1, and processor 1, processor 2, processor 3, and processor 4 population should match)	Optimized population order (Independent channel)	A{1}, B{1}, C{1}, D{1}, A{2}, B{2}, C{2}, D{2}, A{3}, B{3}, C{3}, D{3}, A{4}, B{4}, C{4}, D{4}	Odd number of DIMM population per processor is allowed. i NOTE: Odd number of DIMMs will result in unbalanced memory configurations, which in turn will result in performance loss. It is recommended to populate all memory channels identically with identical DIMMs for best performance. i NOTE: For best performance, 6 DIMMs or 12 DIMMs per processor is recommended. Optimizer population order is not traditional for 16 and 32 DIMMs installations for dual processor. - For 16 DIMMs: A1, A2, A4, A5, B1, B2, B4, B5, C1, C2, C4, C5, D1, D2, D4, D5 - For 32 DIMMs: A1, A2, A4, A5, A7, A8, A10, A11, B1, B2, B4, B5, B7, B8, B10, B11 C1, C2, C4, C5, C7, C8, C10, C11 D1, D2, D4, D5, D7, D8, D10, D11
	Mirroring population order	A{1, 2, 3, 4, 5, 6}, B{1, 2, 3, 4, 5, 6}, C{1, 2, 3, 4, 5, 6}, D{1, 2, 3, 4, 5, 6}, A{7, 8, 9, 10, 11, 12}, B{7, 8, 9, 10, 11, 12}, C{7, 8, 9, 10, 11, 12}, D{7, 8, 9, 10, 11, 12}	Mirroring is supported with 6 or 12 DIMM slots per processor.
	Single rank sparing population order	A{1}, B{1}, C{1}, D{1}, A{2}, B{2}, C{2}, D{2}, A{3}, B{3}, C{3}, D{3}, A{4}, B{4}, C{4}, D{4}	- DIMMs must be populated in the order specified. - Requires two ranks or more per channel.
	Multi rank spare population order	A{1}, B{1}, C{1}, D{1}, A{2}, B{2}, C{2}, D{2}, A{3}, B{3}, C{3}, D{3}, A{4}, B{4}, C{4}, D{4}	- DIMMs must be populated in the order specified. - Requires three ranks or more per channel.
	Fault resilient population order	A{1, 2, 3, 4, 5, 6}, B{1, 2, 3, 4, 5, 6},	Supported with 6 or 12 DIMM slots per processor.

Table 11. Memory population rules (continued)

Processor	Configuration	Memory population	Memory population information
		C{1, 2, 3, 4, 5, 6}, D{1, 2, 3, 4, 5, 6} A{7, 8, 9, 10, 11, 12}, B{7, 8, 9, 10, 11, 12}, C{7, 8, 9, 10, 11, 12}, D{7, 8, 9, 10, 11, 12}	

Removing a memory module

Prerequisites

WARNING: Allow the memory modules to cool after you power off the system. Handle the memory modules by the card edges and avoid touching the components or metallic contacts on the memory module.

CAUTION: To ensure proper system cooling, when processor 1 and processor 2 are installed, memory module blanks must be installed in memory sockets that are not occupied. Remove memory module blanks only if you intend to install memory modules in those sockets.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. Remove the applicable air shroud:
 - [Non-GPU air shroud](#)
 - OR
 - [GPU air shroud](#)

Steps

1. Locate the appropriate memory module socket.

CAUTION: Handle each memory module only by the card edges, ensuring not to touch the middle of the memory module or metallic contacts.

2. Push the ejectors outward on both ends of the memory module socket to release the memory module from the socket.
3. Lift and remove the memory module from the system.




Figure 44. Removing a memory module

NOTE: If you are removing the memory module permanently, install a memory module blank. The procedure to install a memory module blank is similar to that of the memory module.

Next steps

1. [Replace the memory module](#).

Installing a memory module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. Remove the applicable air shroud:
 - [Non-GPU air shroud](#)OR
 - [GPU air shroud](#)

Steps

1. Locate the appropriate memory module socket.

CAUTION: Handle each memory module only by the card edges, ensuring not to touch the middle of the memory module or metallic contacts.

CAUTION: To prevent damage to the memory module or the memory module socket during installation, do not bend or flex the memory module. You must insert both ends of the memory module simultaneously.

2. Open the ejectors on the memory module socket outward to allow the memory module to be inserted into the socket.
3. Align the edge connector of the memory module with the alignment key of the memory module socket, and insert the memory module in the socket.

CAUTION: Do not apply pressure at the center of the memory module; apply pressure at both ends of the memory module evenly.

NOTE: The memory module socket has an alignment key that enables you to install the memory module in the socket in only one orientation.

4. Press the memory module with your thumbs until the socket levers firmly click into place.




Figure 45. Installing a memory module

Next steps

1. Install the applicable air shroud:
 - [GPU air shroud](#)OR
 - [Non-GPU air shroud](#)
2. Follow the procedure listed in [After working inside your system](#).

- Verify if the memory module has been installed properly, by pressing F2 and navigating to **System Setup Main Menu > System BIOS > Memory Settings**. In the **Memory Settings** screen, the System Memory Size must reflect the updated capacity of the installed memory. If the value is incorrect, one or more of the memory modules may not be installed properly. Ensure that the memory module is firmly seated in the memory module socket. Run the system memory test in system diagnostics.

Expansion cards and expansion card risers

An expansion card in the system is an add-on card that can be installed into an expansion slot on the system board or a slot on a riser to add enhanced functionality to the system through the expansion bus.

NOTE: A System Event Log (SEL) event is logged if an expansion card riser is not supported or missing. It does not prevent your system from turning on. However, if a F1/F2 pause occurs, an error message is displayed.

Table 12. Expansion card riser specifications

PCIe slot	Riser	Processor connection	Height	Length	Slot width
1	X8 PCIe Riser 1	Processor 1	Full height	Half length	x8
2	X16 PCIe Riser 1	Processor 1	Full height	Full length	x16
	X8 PCIe Riser 1	Processor 1	Full height	Half length	x8
3	Located on the system board	Processor 1	Low profile	Half length	x16
4	Located on the system board	Processor 2	Low profile	Half length	x16
5	X8 PCIe Riser 2	Processor 2	Full height	Half length	x8
6	X16 PCIe Riser 2	Processor 2	Full height	Full length	x16
	X8 PCIe Riser 2	Processor 2	Full height	Half length	x8

Expansion card installation guidelines

To ensure proper cooling and mechanical fit, the following table provides guidelines for installing expansion cards. The expansion cards with the highest priority must be installed first using the slot priority indicated. All the other expansion cards should be installed in the card priority and slot priority order.

NOTE: The expansion-card slots are not hot-swappable.

Table 13. x16 PCIe riser 1+ x16 PCIe riser 2 configuration

Card type		Slot priority	Riser height	Maximum number of cards supported	Card length	Card height	Maximum PCIe width supported
25G NICs	Intel	2,6	Full height	2	Half length	Full height	x8
		3,4	Low profile	2	Half length	Low profile	x8
GPU	Nvidia	2,6	Full height	2	Full length	Full height	x16
FPGA	Intel	2,6	Full height	2	Half length	Full height	x16
PERC10/11	Dell design	3	Low profile	1	Half length	Low profile	x8
Infiniband HCA EDR	Mellanox	3,4	Low profile	2	Half length	Low profile	x16
		2,6	Full height	2	Half length	Full height	x16

Table 13. x16 PCIe riser 1+ x16 PCIe riser 2 configuration (continued)

Card type		Slot priority	Riser height	Maximum number of cards supported	Card length	Card height	Maximum PCIe width supported
100G NICs	Mellanox	3,4	Low profile	2	Half length	Low profile	x16
		2,6	Full height	2	Half length	Full height	x16
Omni-Path HFI	INTEL	3,4	Low profile	2	Half length	Low profile	x16
		2,6	Full height	2	Half length	Full height	x16
BOSS	Dell design	2,6	Full height	1	Half length	Full height	x4
		2,6	Full height	1	Half length	Full height	x8
		3,4	Low profile	1	Half length	Low profile	x4
		3,4	Low profile	1	Half length	Low profile	x8
External RAID	Dell design	3,4	Low profile	2	Half length	Low profile	x8
		2,6	Full height	2	Half length	Full height	x8
Infiniband HCA FDR	Mellanox	3,4	Low profile	2	Half length	Low profile	x8
40Gb NICs	INTEL	2,6	Full height	2	Half length	Full height	x8
		3,4	Low profile	2	Half length	Low profile	x8
FC32 HBA	QLogic	2,6	Full height	2	Half length	Full height	x8
		3,4	Low profile	2	Half length	Low profile	x8
25G NICs	Broadcom	3,4	Low profile	2	Half length	Low profile	x8
		2,6	Full height	2	Half length	Full height	x8
FC16 HBA	Emulex	2,6	Full height	2	Half length	Full height	x8
		3,4	Low profile	2	Half length	Low profile	x8
		2,3,4,6	Full height, Low profile	4	Half length	Low profile	x8
10Gb NICs		3,4	Low profile	2	Half length	Low profile	x8
		2,6	Full height	2	Half length	Full height	x8
		3,4	Low profile	2	Half length	Low profile	x4
		2,6	Full height	2	Half length	Full height	x4
FC8 HBA		3,4	Low profile	2	Half length	Low profile	x8
		2,6	Full height	2	Half length	Full height	x8
1Gb NICs		2,6	Full height	2	Half length	Full height	x1
		3,4	Low profile	2	Half length	Low profile	x1
		2,6	Full height	2	Half length	Full height	x4
		3,4	Low profile	2	Half length	Low profile	x4
Non-RAID		3,4	Low profile	2	Half length	Low profile	x8
		2,6	Full height	2	Half length	Full height	x8
NVMe PCIe SSD		3,4,2,6	Full height or Low profile	2	Half length	Full height or Low profile	x8

Table 13. x16 PCIe riser 1+ x16 PCIe riser 2 configuration (continued)

Card type		Slot priority	Riser height	Maximum number of cards supported	Card length	Card height	Maximum PCIe width supported
rNDC		Integrated Slot	None	1	None	rNDC	x8
		Integrated Slot	None	1	None	rNDC	x1
		Integrated Slot	None	1	None	rNDC	x4
10 Gb NICs	Intel	2,6	Full height or Low profile	2	Half Length	Full height or Low profile	x8
10 Gb NICs	Intel	3,4	Low profile	2	Half Length	Low profile	x8
10 Gb NICs	Intel	2,6	Full Height	2	Half Length	Full Height	x8
10 Gb NICs	Broadcom	2,3,4,6	Full height, Low profile	4	Half length	Low profile	x8
Non-RAID		3,4,2,6	Full Height or Low Profile	4	Half Length	Full Height	x8
25G NICs	Mellanox	2,6	Full Height	2	Half Length	Full Height	x8
25G NICs	Mellanox	3,4	Low Profile	2	Half Length	Low Profile	x8
100G NICs	Intel	3,4	Low Profile	2	Half Length	Low Profile	x8
100G NICs	Intel	2,6	Full Height	2	Half Length	Full Height	x8
100G NICs	Broadcom	3,4	Low Profile	2	Half Length	Low Profile	x8
100G NICs	Broadcom	2,6	Full Height	2	Half Length	Full Height	x8
PERC-H840 (External Raid)		2,6,3,4	Full Height or Low Profile	4	Half Length	Low Profile	x8
FC32 HBA	Emulex	2,6	Full Height	2	Half Length	Full Height	x8
		3,4	Low Profile	2	Half Length	Low Profile	x8
HBA355e	Dell design	3, 4, 2, 6	Full Height or Low Profile	2	Half Length	Low Profile	x8
100G NICs	Broadcom	3, 4	Low Profile	2	Half Length	Low Profile	x16
100G NICs	Broadcom	2, 6	Full Height	2	Half Length	Full Height	x16
100G NICs	Intel	3, 4	Low Profile	2	Half Length	Low Profile	x16
100G NICs	Intel	2, 6	Full Height	2	Half Length	Full Height	x16

Table 14. x8 PCIe riser 1 + Null riser configuration

Card type	Slot priority	Riser height	Maximum number of cards supported	Card height	Maximum PCIe width supported
PERC10/11	1,2	Full height	2	Low profile	x8
	1	Full height	1	Low profile	x8
Infiniband HCA EDR	3,4	Low profile	2	Low profile	X16
100G NICs	3,4	Low profile	2	Low profile	X16

Table 14. x8 PCIe riser 1 + Null riser configuration (continued)

Card type	Slot priority	Riser height	Maximum number of cards supported	Card height	Maximum PCIe width supported
Omni-Path HFI	3,4	Low profile	2	Low profile	x16
BOSS	1,2	Full height	1	Full height	x4
	1,2	Full height	1	Full height	x8
	3,4	Low profile	1	Low profile	x4
	3,4	Low profile	1	Low profile	x8
External RAID	3,4	Low profile	2	Low profile	x8
	1,2	Full height	2	Full height	x8
Infiniband HCA FDR	3,4	Low profile	2	Low profile	x8
40Gb NICs	1,2	Full height	2	Full height	x8
	3,4	Low profile	2	Low profile	x8
FC32 HBA (QLogic)	1,2	Full height	2	Full height	x8
	3,4	Low profile	2	Low profile	x8
25G NICs	3,4	Low profile	2	Low profile	x8
	1,2	Full height	2	Full height	x8
FC16 HBA	1,2	Full height	2	Full height	x8
	3,4	Low profile	2	Low profile	x8
10Gb NICs	3,4	Low profile	2	Low profile	x8
	1,2	Full height	2	Full height	x8
	3,4	Low profile	2	Low profile	x4
	1,2	Full height	2	Full height	x4
FC8 HBA	3,4	Low profile	2	Low profile	x8
	1,2	Full height	2	Full height	x8
1Gb NICs	1,2	Full height	2	Full height	x1
	3,4	Low profile	2	Low profile	x1
	1,2	Full height	2	Full height	x4
	3,4	Low profile	2	Low profile	x4
Non-RAID	3,4	Low profile	2	Low profile	x8
	1,2	Full height	2	Full height	x8
NVMe PCIe SSD	1,2,3,4	Full height or Low profile	2	Full height or Low profile	x8
rNDC	Integrated Slot	None	1	rNDC	x8
	Integrated Slot	None	1	rNDC	x1
	Integrated Slot	None	1	rNDC	x4
FC16 HBA (Emulex)	1,3,4,2	Full height, Low profile	4	Half length	x8
FC32 HBA (Emulex)	1,2	Full Height	2	Full Height	x8
FC32 HBA (Emulex)	3,4	Low profile	2	Low profile	x8

Table 14. x8 PCIe riser 1 + Null riser configuration (continued)

Card type	Slot priority	Riser height	Maximum number of cards supported	Card height	Maximum PCIe width supported
25 G NICs (Intel)	1,2	Full Height	2	Full Height	x8
25 G NICs(Broadcom)	1,2	Full Height	2	Full Height	x8
25 G NICs (Mellanox)	1,2	Full Height	2	Full Height	x8
25 G NICs (Mellanox)	3,4	Low Profile	2	Low Profile	x8
10 Gb NICs	3,4	Low Profile	2	Low Profile	x8
10 Gb NICs	1,2	Full Height	2	Full Height	x8
10 Gb NICs (Broadcom)	1,3,4,2	Full height, Low profile	4	Half length	x8
Non-RAID	3,4	Low Profile	2	Low Profile	x8
Non-RAID	1,2	Full Height	2	Full Height	x8
Non-RAID	1,2,3,4	Full Height or Low Profile	4	Full Height	x8
100G NICs	3,4	Low Profile	2	Low Profile	x8
External RAID	1,2	Full Height	2	Full Height	x8
External RAID	1,2,3,4	Full Height or Low Profile	4	Low Profile	x8
HBA355e	1, 2, 3, 4	Full Height or Low Profile	2	Low Profile	x8

Table 15. x8 PCIe riser 1 + x8 PCIe riser 2 configuration

Card type	Slot priority	Riser height	Maximum number of cards supported	Card length	Card height	Maximum PCIe width supported
25G NICs Intel	1,2,5,6	Full height	4	Half length	Full height	x8
	3,4	Low profile	2	Half length	Low profile	x8
PERC10	1,2	Full height	2	Half length	Low profile	x8
	1	Full height	1	Half length	Low profile	x8
PERC 11	3,4	Full height	2	Half length	Low profile	x8
	3,4	Full height	1	Half length	Low profile	x8
Infiniband HCA EDR	3,4	Low profile	2	Half length	Low profile	X16
100G NICs	3,4	Low profile	2	Half length	Low profile	X16
Omni-Path HFI	3,4	Low profile	2	Half length	Low profile	x16
BOSS	1,2,5,6	Full height	1	Half length	Full height	x4
	1,2,5,6	Full height	1	Half length	Full height	x8
	3,4	Low profile	1	Half length	Low profile	x4
	3,4	Low profile	1	Half length	Low profile	x8
External RAID	3,4	Low profile	2	Half length	Low profile	x8
	1,2,5,6	Full height	2	Half length	Full height	x8

Table 15. x8 PCIe riser 1 + x8 PCIe riser 2 configuration (continued)

Card type	Slot priority	Riser height	Maximum number of cards supported	Card length	Card height	Maximum PCIe width supported
Infiniband HCA FDR	3,4	Low profile	2	Half length	Low profile	x8
40Gb NICs	1,2,5,6	Full height	4	Half length	Full height	x8
	3,4	Low profile	2	Half length	Low profile	x8
FC32 HBA (QLogic, Emulex)	1,2,5,6	Full height	4	Half length	Full height	x8
	3,4	Low profile	2	Half length	Low profile	x8
25G NICs	3,4	Low profile	2	Half length	Low profile	x8
	1,2,5,6	Full height	4	Half length	Full height	x8
FC16 HBA	1,2,5,6	Full height	4	Half length	Full height	x8
	3,4	Low profile	2	Half length	Low profile	x8
10Gb NICs	3,4	Low profile	2	Half length	Low profile	x8
	1,2,5,6	Full height	4	Half length	Full height	x8
	3,4	Low profile	2	Half length	Low profile	x4
	1,2,5,6	Full height	4	Half length	Full height	x4
FC8 HBA	3,4	Low profile	2	Half length	Low profile	x8
	1,2,5,6	Full height	4	Half length	Full height	x8
1Gb NICs	1,2,5,6	Full height	4	Half length	Full height	x1
	3,4	Low profile	2	Half length	Low profile	x1
	1,2,5,6	Full height	4	Half length	Full height	x4
	3,4	Low profile	2	Half length	Low profile	x4
Non-RAID	3,4	Low profile	2	Half length	Low profile	x8
	1,2,5,6	Full height	4	Half length	Full height	x8
NVMe PCIe SSD	1,2,5,6,3,4	Full height or Low profile	2	Half length	Full height or Low profile	x8
rNDC	Integrated Slot	None	1	None	rNDC	x8
	Integrated Slot	None	1	None	rNDC	x1
	Integrated Slot	None	1	None	rNDC	x4
100G NICs	Intel	Low profile	2	Half length	Low profile	x16
100G NICs	Broadcom	Low profile	2	Half length	Low profile	x16
External RAID	3,4	Low Profile	2	Half length	Low profile	x8
External RAID	1,2,5,6	Full Height	2	Half length	Full Height	x8
External RAID	1,2,5,6,3,4	Full Height or Low Profile	6	Half length	Full Height or Low profile	x8
FC16 HBA (Emulex)	1,2,3,4,5,6	Full height, Low profile	6	Half length	Low profile	x8
10 Gb NICs (Broadcom)	1,2,3,4,5,6	Full height, Low profile	6	Half length	Low profile	x8

Table 15. x8 PCIe riser 1 + x8 PCIe riser 2 configuration (continued)

Card type	Slot priority	Riser height	Maximum number of cards supported	Card length	Card height	Maximum PCIe width supported
Non-RAID	3,4	Low Profile	2	HL	Low Profile	x8
Non-RAID	3,4	Low Profile	2	HL	Low Profile	x8
Non-RAID	1,2,5,6	Full Height	4	HL	Full Height	x8
Non-RAID	1,2,5,6,3,4	Full Height or Low Profile	6	HL	Full Height	x8
HBA355e	1, 2, 5, 6, 3, 4	Full Height or Low Profile	2	Half length	Low Profile	x8

Removing expansion card from the expansion card riser

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. [Remove the expansion card risers](#).

 **NOTE:** The procedure to remove expansion card from riser for all risers is identical.

Steps

1. Open the black expansion card latch on the riser.
2. Open the blue card holder latch on the riser.
3. Hold the expansion card by its edges, and pull the card until the card edge connector disengages from the connector on the riser.





Figure 46. Removing the expansion card from the riser

4. Install a filler bracket if you are not going to replace the expansion card.

i NOTE: You must install a filler bracket over an empty expansion card slot to maintain Federal Communications Commission (FCC) certification of the system. The brackets also keep dust and dirt out of the system and aid in proper cooling and airflow inside the system.

Figure 47. Installing a filler bracket for a riser



Next steps

1. [Install expansion card into the expansion card riser.](#)

Installing expansion card into the expansion card riser

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. If installing a new expansion card, unpack it and prepare the card for installation.

NOTE: For instructions, see the documentation accompanying the card.

4. [Remove the applicable air shroud.](#)
5. [Remove the expansion card risers.](#)

NOTE: The procedure to remove expansion card from riser for all risers is identical.

Steps

1. Open the black expansion card latch on the riser.
2. Open the blue card holder latch on the riser.
3. If installed, remove the filler bracket.




Figure 48. Removing a filler bracket from a riser

NOTE: If applicable, connect the cables to the expansion card.

4. Hold the card by its edges, and align the card edge connector with the connector on the riser.
5. Insert the card edge connector firmly into the expansion card connector until the card is fully seated.
6. Close the expansion card retention latch.




Figure 49. Installing the expansion card into a riser

Next steps

1. [Install the expansion card risers.](#)
2. If applicable, connect the cables to the expansion card.
3. [Install the applicable air shroud.](#)
4. Follow the procedure listed in [After working inside your system.](#)
5. Install any device drivers required for the card as described in the documentation for the card.

Removing the expansion card risers

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove the air shroud.](#)
4. Disconnect any cables connected to the expansion card.

Steps

1. Using the Phillips #2 screwdriver, loosen the screws that secure the riser to the system.
2. Press the blue release tab, and holding the riser by its edges, lift the riser from the riser connector on the system board.




Figure 50. Removing the expansion card x16 PCIe riser 1




Figure 51. Removing the expansion card x16 PCIe riser 2




Figure 52. Removing the expansion card x8 PCIe riser 1




Figure 53. Removing the expansion card x8 PCIe riser 2

Next steps

1. Install the expansion card risers.

Installing the expansion card risers

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).

Steps

1. If removed, install the expansion cards into the expansion card risers.
2. Holding the touch points, align the slots on the riser with the guides on the system board and air shroud.
3. Lower the expansion card riser into place until the expansion card riser connector is fully seated in the connector.
4. Tighten the captive screws to secure the riser to the system.




Figure 54. Installing the expansion card x16 PCIe riser 1




Figure 55. Installing the expansion card x16 PCIe riser 2




Figure 56. Installing the expansion card x8 PCIe riser 1




Figure 57. Installing the expansion card x8 PCIe riser 2

Next steps

1. Install any device drivers required for the card as described in the documentation for the card.
2. [Install the air shroud.](#)
3. Follow the procedure listed in [After working inside your system.](#)

Removing a PCIe expansion card

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove the air shroud.](#)
4. Disconnect any cables connected to the expansion card.

Steps

1. Open the blue expansion card retention latch lock.
2. Hold the expansion card by the edge, and pull the card to disconnect from the system board connector.




Figure 58. Removing an expansion card from the system board

3. If you are not replacing the expansion card, install a filler bracket by performing the following steps:
 - a. Align the slot on the filler bracket with the tab on the expansion card slot.
 - b. Align the filler bracket with the slot on the system.
 - c. Push the filler bracket downward until firmly seated.
 - d. Close the blue expansion card retention latch.




Figure 59. Installing the filler bracket

Next steps

1. [Install an expansion card.](#)

Installing a PCIe expansion card

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).

Steps

1. Unpack the expansion card and prepare it for installation.
For instructions, see the documentation accompanying the card.
2. If you are installing a new card, remove the filler bracket.
 - a. Open the blue expansion card retention latch lock.
 - b. Slide the filler bracket out of the system.




Figure 60. Removing the filler bracket

NOTE: Store the filler bracket for future use. Filler brackets must be installed in empty expansion card slots to maintain FCC certification of the system. The brackets also keep dust and dirt out of the system and aid in proper cooling and airflow inside the system.

3. Holding the card on the edges, align the card with the expansion card connector on the system board.
4. Press the expansion card firmly into the expansion card connector on the system board until the card is fully seated.
5. Close the blue expansion card retention latch.




Figure 61. Installing an expansion card on the system board

Next steps

1. Connect the required cables to the expansion card.
2. [Install the air shroud.](#)
3. Follow the procedure listed in [After working inside your system.](#)

GPU card installation guidelines

- Ensure that both the processors are installed.
- The processor must use the GPU kit low-profile heat sink.
- To ensure adequate cooling when one or more GPUs are installed, the ambient inlet temperature is restricted to 30°C for CPU 150 W/8 C, 165 W/12 C, 200 W, 205 W. For more information, see the Ambient temperature limitations section in the PowerEdge R840 Technical Specs at www.dell.com/poweredgemanuals.
- All GPUs must be of the same type and model.
- The cover on the GPU air shroud must be removed before installing the GPU.
- Ensure that high performance fans and GPU air shroud are installed.

NOTE: When using systems with GPU, ensure that you install PSUs with 1100 W or higher, and set the PSU configuration to non-redundant mode.

Removing a GPU

Prerequisites

1. Follow the safety guidelines listed in [Safety Instructions](#).
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove the GPU air shroud cover.](#)
4. [Remove the expansion card riser.](#)

Steps

1. Disconnect the GPU power cable from the PIB.
2. Open the expansion card latch and the card holder latch on the riser.




Figure 62. Removing the GPU card from the riser

3. Holding the card by its edges, lift to release it from the connector on the riser.
 4. Disconnect the GPU power cable from the GPU.
 5. If you are removing the GPU permanently, install a filler bracket.
- NOTE:** You must install a filler bracket over an empty expansion card slot to maintain Federal Communications Commission (FCC) certification of the system. The brackets also keep dust and dirt out of the system and aid in proper cooling and airflow inside the system. The filler bracket is necessary to maintain proper thermal conditions.

Next steps

Replace the GPU.

Installing a GPU

Prerequisites

1. Follow the safety guidelines listed in [Safety Instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the GPU air shroud cover](#).
4. Remove the expansion card riser.

Steps

1. Connect the GPU power cable to the connector on the GPU.
 2. Open the expansion card latch and the card holder latch on the riser.
 3. Remove the existing expansion card or filler bracket from the riser.
- NOTE:** You must install a filler bracket over an empty expansion card slot to maintain Federal Communications Commission (FCC) certification of the system. The brackets also keep dust and dirt out of the system and aid in proper cooling and airflow inside the system.
- NOTE:** The filler bracket is necessary to maintain proper thermal conditions.
4. Route the GPU power cable through the slot on the riser bracket.

5. Holding the card by its edges, position the card so that the card aligns with the expansion card connector.
6. Insert the card firmly into the expansion card connector until the card is fully seated.
7. Close the expansion card latch and the card holder latch.




Figure 63. Installing the GPU card on the riser

8. Connect the other end of the GPU power cable to the PIB.

Next steps

1. [Install the top cover of the GPU air shroud.](#)
2. Follow the procedure listed in [After working inside your system.](#)

Optional M.2 SSD module

The BOSS card is a simple RAID solution card designed specifically for booting a server's operating system. The card supports up to two 6 Gbps M.2 SATA drives. The BOSS adapter card has a x8 connector using PCIe gen 2.0 x2 lanes, available in both the low-profile and full-height form factor.

Removing the M.2 SSD module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove the air shroud.](#)
4. If installed, [remove the rear drive cage.](#)
5. Remove the BOSS card.

NOTE: The procedure to remove the BOSS card is similar to the [removing an expansion card.](#)

Steps

1. Loosen the screw and lift the retention strap that secures the M.2 SSD module on the BOSS card.
2. Lift the M.2 SSD module and slide it out of the connector on the BOSS card.




Figure 64. Removing the M.2 SSD module

Next steps

Replace the M.2 SSD card module.

Installing the M.2 SSD module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. Remove the BOSS card.

NOTE: The procedure to remove the BOSS card is similar to the [removing an expansion card](#).

Steps

1. Align and slide the M.2 BOSS card module at a 45-degree angle, into the SATA connector on the M.2 BOSS card.
2. Push the module down until firmly seated on the card.
3. Secure the module to the card with the retention strap, and using the Phillips #1 screwdriver tighten the screw.




Figure 65. Installing the M.2 SSD module

Next steps

1. Install the BOSS card.
NOTE: The procedure to install the BOSS card is similar to the [removing an expansion card](#).
2. [Install the applicable air shroud](#).
3. Follow the procedure listed in [After working inside your system](#).

Processors and heat sinks

The processor controls memory, peripheral interfaces, and other components of the system. The system can have more than one processor configurations.

The heat sink absorbs the heat generated by the processor, and helps the processor to maintain its optimal temperature level.

Table 16. Processor wattage and heat sink dimensions

Heat sink	
Heat sink type	Heat sink dimensions
1U heat sink For GPU configuration	L x W x H: 128 mm x 82 mm x 25.5 mm
2U heat sink For non-GPU configuration	L x W x H: 110 mm x 82 mm x 61 mm

Dual processor configuration

The system will function normally if there are two processors installed in the CPU 1 and 2 sockets. Processor and memory blanks associated with CPU 3 and 4 are not required to be installed. For information on the expansion card slots supported on dual processor, see Expansion card riser specifications section in the PowerEdge R840 Technical Specs at www.dell.com/poweredgemanuals.

Quad processor configuration

For quad processor configurations, all installed risers will be functional.

Removing a processor and heat sink module

Prerequisites

WARNING: The heat sink may be hot to touch for some time after the system is powered down. Allow the heat sink to cool before removing it.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).

Steps

1. Using a Torx #T30 screwdriver, loosen the screws on the heat sink in the order below:
 - a. Loosen the first screw three turns.
 - b. Loosen the second screw completely.
 - c. Return to the first screw and loosen it completely.
2. Pushing both blue retention clips simultaneously, lift the processor and heat sink module (PHM).
3. Set the PHM aside with the processor side facing up.




Figure 66. Removing the processor and heat sink module 1U




Figure 67. Removing the processor and heat sink module 2U

Next steps

1. [Replace the processor and heat sink module.](#)

Removing the processor from the processor and heat sink module

Prerequisites

⚠ WARNING: The heat sink may be hot to touch for some time after the system has been powered down. Allow the heat sink to cool before removing it.

i NOTE: Only remove the processor from the processor and heat sink module if you are replacing the processor or heat sink. This procedure is not required when replacing a system board.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the processor and heat sink module.](#)

Steps

1. Place the heat sink with the processor side facing up.
2. Insert a flat blade screwdriver into the release slot marked with a yellow label. Twist (do not pry) the screwdriver to break the thermal paste seal.
3. Push the retaining clips on the processor bracket to unlock the bracket from the heat sink.




Figure 68. Loosening the processor bracket

4. Lift the bracket and the processor from the heat sink, and place the processor connector side down on the processor tray.
5. Flex the outer edges of the bracket to release the bracket from the processor.

NOTE: Ensure that the processor and the bracket are placed in the tray after you remove the heat sink.



Figure 69. Removing the processor bracket

Next steps

1. [Install the processor into the processor and heat sink module.](#)

Installing the processor into a processor and heat sink module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).

3. Remove the processor and heat sink module.

Steps

1. Place the processor in the processor tray.

i **NOTE:** Ensure that the pin 1 indicator on the processor tray is aligned with the pin 1 indicator on the processor.

2. Flex the outer edges of the bracket around the processor ensuring that the processor is locked into the clips on the bracket.

i **NOTE:** Ensure that the pin 1 indicator on the bracket is aligned with the pin 1 indicator on the processor before placing the bracket on the processor.

i **NOTE:** Ensure that the processor and the bracket are placed in the tray before you install the heat sink.



Figure 70. Installing the processor bracket

3. If you are using an existing heat sink, remove the thermal grease from the heat sink by using a clean lint-free cloth.
4. Use the thermal grease syringe included with your processor kit to apply the grease in a quadrilateral design on the top of the processor.

Δ **CAUTION:** Applying too much thermal grease can result in excess grease coming in contact with and contaminating the processor socket.

i **NOTE:** The thermal grease syringe is intended for single use only. Dispose the syringe after you use it.




Figure 71. Applying thermal grease on top of the processor

5. Place the heat sink on the processor and push down on the base of the heat sink until the bracket locks onto the heat sink.

NOTE:

- Ensure that the two guide pin holes on the bracket match the guide holes on the heat sink.
- Do not press on the heat sink fins.
- Ensure that the pin 1 indicator on the heat sink is aligned with the pin 1 indicator on the bracket before placing the heat sink onto the processor and bracket.




Figure 72. Installing the heat sink onto the processor 1U




Figure 73. Installing the heat sink onto the processor 2U

Next steps

1. [Install the processor and heat sink module.](#)

Installing a processor and heat sink module

Prerequisites

CAUTION: Never remove the heat sink from a processor unless you intend to replace the processor. The heat sink is necessary to maintain proper thermal conditions.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. Remove the processor blank and CPU dust cover, if installed.

Steps

1. Align the Pin1 indicator on the heat sink with the indicator on the system board and place the processor and heat sink module (PHM) on the processor socket.

CAUTION: To avoid damaging the fins on the heat sink, do not press down on the heat sink fins.

NOTE: Ensure that the PHM is held parallel to the system board to prevent damaging the components.

2. Push the blue retention clips inward to allow the heat sink to drop in place.
3. Using the Torx #T30 screwdriver, tighten the screws on the heat sink in the order below:
 - a. Partially tighten the first screw (approximately 3 turns).
 - b. Tighten the second screw completely.

c. Return to the first screw and tighten it completely.

If the PHM slips off the blue retention clips when the screws are partially tightened, follow these steps to secure the PHM:

- a. Loosen both the heat sink screws completely.
- b. Lower the PHM on to the blue retention clips.
- c. Secure the PHM to the system board, following the replacement instructions listed in this step mentioned above.

NOTE: The processor and heat sink module retention screws should not be tightened to more than 0.13 kgf-m (1.35 N.m or 12 in-lbf).




Figure 74. Installing a processor and 1U heat sink module




Figure 75. Installing a processor and 2U heat sink module

Next steps

1. Install the air shroud.

2. Follow the procedure listed in [After working inside your system](#)

Optional IDSDM or vFlash module

NOTE: The write-protect switch is on the IDSDM or vFlash module.

Removing IDSDM or vFlash module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. [Remove the expansion card riser 1](#).

Steps

1. Locate the IDSDM or vFlash connector on riser 1.
2. Holding the pull tab, lift the IDSDM or vFlash module out of the system.




Figure 76. Removing IDSDM or vFlash module

NOTE: There are two dip switches on the IDSDM or vFlash module for write-protection.

NOTE: If you are replacing the IDSDM or vFlash module, [remove the microSD cards](#).

Next steps

[Install the IDSDM or vFlash module](#).

Installing IDSDM or vFlash module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. [Remove the expansion card riser 1](#).

Steps

1. Locate the IDSDM or vFlash connector on riser 1.
2. Align IDSDM or vFlash module with the connector on the riser.
3. Push IDSDM or vFlash module until it is firmly seated in the connector on the riser.




Figure 77. Installing IDSDM or vFlash module

Next steps

1. [Install the microSD cards](#).
NOTE: Reinstall the microSD cards into the same slots based on the labels you had marked on the cards during removal.
2. [Install the expansion card riser 1](#).
3. [Install the air shroud](#).
4. Follow the procedure listed in [After working inside your system](#).

Removing the MicroSD card

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).

4. [Remove the expansion card riser 1.](#)
5. [Remove the IDSMD or vFlash module.](#)

Steps

1. Locate the MicroSD card slot on the IDSMD or vFlash module, and press the card to partially release it from the slot.




Figure 78. Removing the MicroSD card

2. Hold the MicroSD card and remove it from the slot.

NOTE: Temporarily label each MicroSD card with its corresponding slot number after removal.

Next steps

[Install the MicroSD card.](#)

Installing the MicroSD card

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud.](#)
4. [Remove the expansion card riser 1.](#)
5. [Remove the IDSMD or vFlash module.](#)

NOTE: To use an MicroSD card with your system, ensure that the **Internal SD Card Port** is enabled in System Setup.

NOTE: If reinstalling, ensure that you install the MicroSD cards into the same slots based on the labels you had marked on the cards during removal.

Steps

1. Locate the MicroSD card connector on the IDSMD or vFlash module. Orient the MicroSD card appropriately and insert the contact-pin end of the card into the slot.




Figure 79. Installing the MicroSD card

NOTE: The slot is keyed to ensure correct insertion of the card.

2. Press the card into the card slot to lock it into place.

Next steps

1. [Install the IDSDM or vFlash module.](#)
2. [Install the expansion card riser 1.](#)
3. [Install the air shroud.](#)
4. Follow the procedure listed in [After working inside your system.](#)

Network daughter card

Removing network daughter card

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove the air shroud.](#)
4. [Remove the expansion card riser 1.](#)

Steps

1. Using a Phillips #2 screwdriver, loosen the captive screws that secure the network daughter card (NDC) to the system board.
2. Hold the NDC by the edges, and lift to disengage it from the connector on the system board.
3. Slide the NDC towards the front of the system until the Ethernet connectors are clear of the slot in the back of the system.




Figure 80. Removing network daughter card

Next steps

1. [Replace the Network daughter card.](#)

Installing network daughter card

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. [Remove the expansion card riser 1](#).

Steps

1. Orient the NDC so that the Ethernet connectors fit through the slot in the chassis.
2. Align the captive screws on the card with the screw holes on the system board.
3. Press the touch points on the card until the card connector is firmly seated on the system board connector.
4. Using a Phillips #2 screwdriver, tighten the captive screws to secure the NDC to the system board.




Figure 81. Installing the network daughter card

Next steps

1. [Install the expansion card riser 1](#) or the [rear drive cage](#), depending on the configuration of your system.
2. [Install the air shroud](#).
3. Follow the procedure listed in [After working inside your system](#).

Drive backplane

The drive backplanes supported in PowerEdge R840 are shown here:




Figure 82. 8 x 2.5-inch backplane

- | | |
|---------------------------|-------------------------------|
| 1. miniSAS hard drive B 1 | 2. miniSAS hard drive A 1 |
| 3. Power cable connector | 4. Backplane signal connector |




Figure 83. 24 x 2.5-inch (24 NVMe) backplane

- | | |
|-------------------------------|-------------------------------|
| 1. PCIe cable connector | 2. PCIe cable connector |
| 3. PCIe cable connector | 4. PCIe cable connector |
| 5. Backplane signal connector | 6. SAS/SATA cable connector |
| 7. Power cable connector | 8. Backplane signal connector |
| 9. Power cable connector | |




Figure 84. 2.5 inch (x24) SAS/SATA (expander) with universal slot for NVMe backplane


- | | |
|---|------------------------------------|
| 1. SAS cable connector A | 2. SAS cable connector B |
| 3. Backplane signal connector(J_BP_SIG) | 4. Power cable connector (J_PWR_A) |
| 5. Power cable connector (J_PWR_B) | 6. PCIe cable connector |
| 7. PCIe cable connector | 8. PCIe cable connector |
| 9. PCIe cable connector | 10. PCIe cable connector |
| 11. PCIe cable connector | |

Drive mapping

Table 17. Supported drive options

Chassis options		Configurations
Twenty-four drive chassis		Up to twenty four 2.5 inch SAS/SATA front accessible drives in slots 0 through 23 Up to twenty four 2.5 inch SAS/SATA front accessible drives in slots 0 through 23 + two 2.5 inch rear accessible SAS/SATA drives

Table 17. Supported drive options (continued)

Chassis options		Configurations
		Up to twelve 2.5 inch SAS/SATA front accessible drives in slots 0 through 11 + twelve SAS/SATA/NVMe front accessible drives in slots 12 through 23
		Up to twenty four 2.5 inch NVMe front accessible drives in slots 0 through 23
		Up to eight 2.5 inch SAS/SATA/NVMe front accessible drives in slots 0 through 7 + sixteen NVMe front accessible drives in Bay-0 slots 8 through 11 + Bay-1 slots 0 through 11.
Eight hard drive chassis		Up to eight 2.5 inch SAS/SATA front accessible drives in slots 0 through 7 Up to eight 2.5 inch SATA front accessible drives in slots 0 through 7

Removing drive backplane

Prerequisites

CAUTION: To prevent damage to the drives and backplane, remove the drives from the system before removing the backplane.

CAUTION: Note the number of each drive and temporarily label them before you remove the drive so that you can replace them in the same location.

NOTE: The procedure to remove the backplane is similar for all backplane configurations.

- Follow the safety guidelines listed in [Safety instructions](#).
- Follow the procedure listed in [Before working inside your system](#).
- If applicable, [remove the front bezel](#).
- [Remove all drives from the front bay](#).
- [Remove the air shroud](#).
- [Remove the cooling fan assembly](#).

Steps

- Disconnect all the PERC cables from the adapter PERC cards.
- Press and hold the blue release tabs, and lift the backplane up to disengage the slots on the backplane from the hooks on the system.

NOTE: If your backplane has an expander board, the procedure to remove remains the same.




Figure 85. Removing drive backplane

3. Lift the backplane and place it on the top of the hard drive bay, and then disconnect the power and I2C cables.
4. If applicable, disconnect all the slimline SAS cables from the system board.

Next steps

1. [Replace the drive backplane.](#)

Installing drive backplane

Prerequisites

NOTE: The procedure to install the backplane is similar for all backplane configurations.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the front bezel](#), if applicable.
4. [Remove all drives from the front bay](#).
5. [Remove the air shroud](#).
6. [Remove the cooling fan assembly](#).

Steps

1. Connect the cables.
 - a. If applicable, connect the slimline SAS, I2C, and power cables to the backplane.
 - b. Connect the I2C and power cables to the system board.
2. Holding the blue release tabs, align the slots on the backplane with the hooks on the system.
3. Lower the drive backplane until the blue release tabs snap into place.




Figure 86. Installing drive backplane

4. If applicable, connect the slimline SAS cable to the system board.
5. If applicable, connect the PERC cables to the adapter PERC cards.

Next steps

1. [Install the cooling fan assembly.](#)
2. [Install the air shroud.](#)
3. [Install the drives.](#)
4. [Install the front bezel](#), if applicable.
5. Follow the procedure listed in [After working inside your system.](#)

Cable routing




Figure 87. Cable routing - 8 x 2.5 inch, SATA drive backplane




Figure 88. Cable routing - 8 x 2.5 inch, SAS/SATA drive backplane with GPU and single PERC card (Low profile riser)




Figure 89. Cable routing - 8 x 2.5 inch, (SAS/SATA) drive backplane with single PERC card

NOTE: If a GPU card is installed, the PERC card must be installed in the low profile expansion card slot on the system board.




Figure 90. Cable routing - 24 x 2.5 inch, (SAS/SATA) drive backplane supporting x12 universal (SAS/SATA/NVMe) slots with GPU and single PERC card




Figure 91. Cable routing - 24 x 2.5 inch, (SAS/SATA) drive backplane supporting with single PERC card




Figure 92. Cable routing - 24 x 2.5 inch, (SAS/SATA) drive backplane with dual PERC card




Figure 93. Cable routing - 26 x 2.5 inch, (SAS, 24 front + 2 rear) drive backplane with single PERC card




Figure 94. Cable routing - 24 x 2.5 inch, (12 SAS + 12 universal) drive backplane




Figure 95. Cable routing - 24 x 2.5 inch, (12 SAS + 12 universal) drive backplane with single PERC card




Figure 96. Cable routing - 24 x 2.5-inch, (16 NVMe + 8 universal) drive backplane with single PERC card




Figure 97. Cable routing - 24 x 2.5 inch, (16 NVMe + 8 universal) drive backplane

System battery

Replacing system battery

Prerequisites

WARNING: There is a danger of a new battery exploding if it is incorrectly installed. Replace the battery only with the same or equivalent type recommended by the manufacturer. For more information, see the safety information that shipped with your system.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. If applicable, disconnect the power or data cables from the expansion card riser x16 PCIe riser 2 or x8 PCIe riser 2.
5. If installed, [remove the expansion card risers](#).
6. If installed, [remove the PCIe expansion cards](#).

Steps

1. Locate the battery socket. For more information, see the [System board jumpers and connectors](#) section.

CAUTION: To avoid damage to the battery connector, you must firmly support the connector while installing or removing a battery.

2. Use a plastic scribe to pry out the system battery.



Figure 98. Removing system battery

3. To install a new system battery, hold the battery with the positive side facing up and slide it under the securing tabs.
4. Press the battery into the connector until it snaps into place.




Figure 99. Installing system battery

Next steps

1. If applicable, [install the low profile PCIe cards](#).
2. If applicable, [install the expansion card riser x16 PCIe riser 2 or x8 PCIe riser 2](#).
3. Connect the power or data cables to the expansion card risers.
4. [Install air shroud](#).
5. Follow the procedure listed in [After working inside your system](#).
6. While booting, press F2 to enter the System Setup and ensure that the battery is operating properly.
7. Enter the correct time and date in the System Setup **Time** and **Date** fields.
8. Exit the System Setup.

Optional USB 3.0 module

The USB 3.0 module cable connects to the internal USB port on the system board.

NOTE: The optional USB 3.0 module is supported only on the 8 x 2.5-inch system configuration.

Removing USB 3.0 module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. [Remove the cooling fan assembly](#).
5. [Remove the internal USB memory key](#).

NOTE: Ensure that you note the routing of the cables as you remove them from the system board. Route these cables properly when you replace them to prevent them from being pinched or crimped.

Steps

1. Disconnect the cables from the system board.
2. Using the Phillips #2 screwdriver, loosen the screw on the USB 3.0 module.
3. Slide the USB 3.0 module out of the system.




Figure 100. Removing USB 3.0 module

Next steps

1. [Replace the USB 3.0 module.](#)

Installing USB 3.0 module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).
4. [Remove the cooling fan assembly](#).

Steps

1. Route the power and the USB cables on the USB 3.0 module through the USB 3.0 module slot on the front of the system.
2. Insert the USB 3.0 module into the slot on the front panel.
3. Align the screw on the module with the screw hole on the system.
4. Using a Phillips #2 screwdriver, tighten the screw to secure the module to the system.
5. Route and connect the USB cable to internal USB port and power cable to the backplane power connector on the system board. To locate the connector, see the [System board jumpers and connectors](#) section.




Figure 101. Installing USB 3.0 module

Next steps

1. Install the internal USB memory key.
2. Install the cooling fan assembly.
3. Install the air shroud.
4. Follow the procedure listed in [After working inside your system](#).

Optional internal USB memory key

An optional USB memory key installed inside your system can be used as a boot device, security key, or mass storage device. To boot from the USB memory key, configure the USB memory key with a boot image and then specify the USB memory key in the boot sequence in System Setup.

An optional USB memory key can be installed in the internal USB 3.0 port.

i **NOTE:** To locate the internal USB port on the system board, see the System board jumpers and connectors section.

Replacing optional internal USB memory key

Prerequisites

⚠ CAUTION: To avoid interference with other components in the server, the maximum permissible dimensions of the USB memory key are 15.9 mm wide x 57.15 mm long x 7.9 mm high.

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the air shroud](#).

Steps

1. Locate the USB port or USB memory key on the system board.
To locate the internal USB port on the system board, see the [System board jumpers and connectors](#) section.

2. If installed, remove the USB memory key from the USB port.
3. Insert the replacement USB memory key into the USB port.

Next steps

1. [Install the air shroud.](#)
2. Follow the procedure listed in [After working inside your system.](#)
3. While booting, press F2 to enter **System Setup** and verify that the system detects the USB memory key.

Optional optical drive

Optical drives retrieve and store data on optical discs such as CD and DVD. Optical drives can be categorized into two basic types: optical disc readers and optical disc writers.

 **NOTE:** Optical drives are supported only on the 8 x 2.5-inch system configuration.

Removing optical drive

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. If applicable, [remove the front bezel.](#)

Steps

1. Press the release tab to release the optical drive.
2. Disconnect the power and data cables from the connectors on the optical drive.

 **NOTE:** Ensure that you note the routing of the power and data cable on the side of the system as you remove them from the system board and drive.

3. Slide the optical drive out of the system until it is free of the optical drive slot.




Figure 102. Removing optical drive

4. If you are not installing a new optical drive, install the optical drive blank.

i **NOTE:** The procedure to install an optical blank is similar to the optical drive.

Next steps

1. [Replace the optical drive.](#)

Installing optical drive

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. If applicable, [remove the front bezel](#).

Steps

1. If installed, remove the optical drive blank.

i **NOTE:** The procedure to remove an optical blank is similar to the optical drive.

2. Align the optical drive with the optical drive slot on the front of the system.
3. Slide in the optical drive until the release tab snaps into place.
4. Connect the power and data cables to the connectors on the optical drive.

i **NOTE:** Route the cables properly to prevent them from being pinched or crimped.

Next steps




Figure 103. Installing optical drive

1. If applicable, [install the front bezel](#).
2. Follow the procedure listed in [After working inside your system](#).

Power supply units

The power supply unit (PSU) is an internal hardware component which supplies power to the components in the system.

Your system supports one of the following:

- Two 2400 W, 2000 W, 1600 W, 1100 W, or 750 W AC PSUs
- Two 750 W DC PSUs (for China only)
- Two 1100 W DC PSUs
- Two 1100 W or 750 W (for China only) Mixed Mode HVDC PSUs

NOTE: For more information about power supply units, see the PowerEdge R840 Technical Specs at www.dell.com/poweredgemanuals..

CAUTION: If two PSUs are installed, both the PSUs must have the same type of label. For example, **Extended Power Performance (EPP) label**. Mixing PSUs from previous generations of PowerEdge servers is not supported, even if the PSUs have the same power rating. Mixing PSUs result in mismatch condition or failure to turn on the system.

NOTE: When two identical PSUs are installed, power supply redundancy (1+1 – with redundancy or 2+0 – without redundancy) is configured in system BIOS. In redundant mode, power is supplied to the system equally from both PSUs when Hot Spare is disabled. When Hot Spare is enabled, one of the PSUs is put into the sleep mode when system utilization is low to maximize efficiency.

NOTE: If two PSUs are used, they must be of the same maximum output power.

NOTE: In a single PSU configuration, install the PSU in bay 1 (bottom PSU slot).

Hot spare feature

Your system supports the hot spare feature that significantly reduces the power overhead associated with power supply unit (PSU) redundancy.

When the hot spare feature is enabled, one of the redundant PSUs is switched to the sleep state. The active PSU supports 100 percent of the load, thus operating at higher efficiency. The PSU in the sleep state monitors output voltage of the active PSU. If the output voltage of the active PSU drops, the PSU in the sleep state returns to an active output state.

If having both PSUs active is more efficient than having one PSU in the sleep state, the active PSU can also activate the sleeping PSU.

The default PSU settings are as follows:

- If the load on the active PSU is more than 50 percent, then the redundant PSU is switched to the active state.
- If the load on the active PSU falls below 20 percent, then the redundant PSU is switched to the sleep state.

You can configure the hot spare feature by using the iDRAC settings. For more information about iDRAC settings, see the *Integrated Dell Remote Access Controller User's Guide* available at <https://www.dell.com/idracmanuals>.

Removing a power supply unit blank

Prerequisites

Follow the safety guidelines listed in [Safety instructions](#).

Steps

If you are installing a second PSU, remove the PSU blank in the bay by pulling the blank outward.

CAUTION: To ensure proper system cooling, the PSU blank must be installed in the second PSU bay in a non-redundant configuration. Remove the PSU blank only if you are installing a second PSU.




Figure 104. Removing a power supply unit blank

Next steps

Install the PSU or PSU blank.

Installing a power supply unit blank

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Install the power supply unit (PSU) blank only in the second PSU bay.

Steps

Align the PSU blank with the PSU slot and push it into the PSU slot until it clicks into place.




Figure 105. Installing a power supply unit blank

Removing power supply unit

The procedure for removing AC and DC PSUs is identical.

Prerequisites

CAUTION: The system needs one power supply unit (PSU) for normal operation. On power-redundant systems, remove and replace only one PSU at a time in a system that is powered on.

1. Follow the safety guidelines listed in [Safety instructions](#).
1. Disconnect the power cable from the power source and from the PSU you intend to remove, and then remove the cable from the strap on the PSU handle.
2. To remove the PSU, remove optional strain relief bar and strain relief bar attachment bracket, if they interfere with the PSU removal.

For information about the strain relief bar attachment bracket and strain relief bar, see the system's Rail Installation Guide at <https://www.dell.com/poweredgemanuals>.

Steps

Press the release latch, and holding the PSU handle slide the PSU out of the system.




Figure 106. Removing power supply unit

Next steps

1. Install the [PSU](#) or the [PSU blank](#).

Installing power supply unit

The procedure for installing AC and DC PSUs is identical.

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. For systems that support redundant PSU, ensure that both the PSUs are of the same type and have the same maximum output power.

NOTE: The maximum output power (shown in watts) is listed on the PSU label.

Steps

Slide the PSU into the system until the PSU is fully seated and the release latch snaps into place.




Figure 107. Installing power supply unit

Next steps

1. If you have removed the strain relief bar attachment bracket and strain relief bar, reinstall them. For information about the strain relief bar attachment bracket and strain relief bar, see the system's Rail Installation Guide at <https://www.dell.com/poweredgemanuals>.
2. Connect the power cable to the PSU, and plug the cable into a power outlet.

CAUTION: When connecting the power cable to the PSU, secure the cable to the PSU with the strap.

NOTE: When installing, hot swapping, or hot adding a new PSU, wait for 15 seconds for the system to recognize the PSU and determine its status. The PSU redundancy may not occur until discovery is complete. Wait until the new PSU is discovered and enabled before you remove the other PSU. The PSU status indicator turns green to signify that the PSU is functioning properly.

Wiring instructions for a DC power supply unit

Your system supports up to two $-(48-60)$ V DC power supply units (PSUs).

NOTE: For equipment using $-(48-60)$ V DC power supply units (PSUs), a qualified electrician must perform all connections to DC power and to safety grounds. Do not attempt connecting to DC power or installing grounds yourself. All electrical wiring must comply with applicable local or national codes and practices. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow all safety instructions that came with the product.

CAUTION: Wire the unit with copper only, unless otherwise specified, use only 10 American Wire Gauge (AWG) wire rated minimum 90°C for source and return. Protect the $-(48-60)$ V DC (1 wire) with a branch circuit over-current protection rated 50 A for DC with a high interrupt current rating.

CAUTION: Connect the equipment to a $-(48-60)$ V DC supply source that is electrically isolated from the AC source (reliably grounded $-(48-60)$ V DC SELV source). Ensure that the $-(48-60)$ V DC source is efficiently secured to earth (ground).

NOTE: A readily accessible disconnect device that is suitably approved and rated shall be incorporated in the field wiring.

Input requirements

- Supply voltage: $-(48-60)$ V DC
- Current consumption: 32 A (maximum)

Kit contents

- Dell part number 6RYJ9 terminal block or equivalent (1)
- #6-32 nut equipped with lock washer (1)

Required tools

Wire-stripper pliers capable of removing insulation from size 10 AWG solid or stranded, insulated copper wire.

NOTE: Use alpha wire part number 3080 or equivalent (65/30 stranding).

Required wires

- One UL 10 AWG, 2 m maximum (stranded) black wire [$-(48-60)$ V DC].
- One UL 10 AWG, 2 m maximum (stranded) red wire (V DC return).
- One UL 10 AWG, 2 m maximum, green with a yellow stripe, stranded wire (safety ground).

Assembling and connecting safety ground wire

Prerequisites

NOTE: For equipment using $-(48-60)$ V DC power supply units (PSUs), a qualified electrician must perform all connections to DC power and to safety grounds. Do not attempt connecting to DC power or installing grounds yourself. All electrical wiring must comply with applicable local or national codes and practices. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow all safety instructions that came with the product.

Steps

1. Strip the insulation from the end of the green or yellow wire, exposing approximately 4.5 mm (0.175 inch) of copper wire.
2. Using a hand-crimping tool (Tyco Electronics, 58433-3 or equivalent), crimp the ring-tongue terminal (Jeerson Terminals Inc., R5-4SA or equivalent) to the green and yellow wire (safety ground wire).

3. Connect the safety ground wire to the grounding post on the back of the system by using a #6-32 nut equipped with a locking washer.

Assembling DC input power wires

Prerequisites

-  **NOTE:** For equipment using –(48–60) V DC power supply units (PSUs), a qualified electrician must perform all connections to DC power and to safety grounds. Do not attempt connecting to DC power or installing grounds yourself. All electrical wiring must comply with applicable local or national codes and practices. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow all safety instructions that came with the product.

Steps

1. Strip the insulation from the ends of the DC power wires, exposing approximately 13 mm (0.5 inch) of copper wire.

 **NOTE:** Reversing polarity when connecting DC power wires can permanently damage the power supply or the system.
2. Insert the copper ends into the mating connectors and tighten the captive screws at the top of the mating connector using a Phillips #2 screwdriver.

 **NOTE:** To protect the power supply from electrostatic discharge, the captive screws must be covered with the rubber cap before inserting the mating connector into the power supply.
3. Rotate the rubber cap clockwise to fix it over the captive screws.
4. Insert the mating connector into the power supply.

Power Interposer Board

The Power Interposer Board (PIB) is a board that connects the hot swappable power supply units (PSUs) to the system board.

Removing Power Interposer Board

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. Remove the applicable air shroud:
 - a. [Non-GPU air shroud](#)
 - b. [Expansion card riser 2](#)OR
 - a. [GPU air shroud](#)
 - b. [Expansion card riser 2](#)
4. [Remove the power supply units](#)

 **CAUTION:** To prevent damage to the power interposer board, you must remove the power supply module (s) or power supply blank from the system before removing the power interposer board or power distribution board.

Steps

1. Disconnect the cables connected from the power interposer board (PIB) to the system board, and remove the cables from the cable retention brackets.

 **NOTE:** Observe the routing of the cable as you remove it from the system. Route the cable properly when you replace it to prevent the cable from being pinched or crimped.
2. Using a Phillips #2 screwdriver, remove the screw securing the PIB to the system.
3. Holding the blue touch point on the PIB, gently lift, to release it from the PSU cage, and slide it out.

4. Lift the PIB away from the system.




Figure 108. Removing power interposer board

Next steps

1. [Replace the power interposer board \(PIB\).](#)

Installing Power Interposer Board

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. Remove the applicable air shroud:
 - a. [Non-GPU air shroud](#)
 - b. [Expansion card riser 2](#)OR
 - a. [GPU air shroud](#)
 - b. [Expansion card riser 2](#)
4. [Remove the power supply units](#)

CAUTION: To prevent damage to the power interposer board, you must remove the power supply module (s) or power supply blank from the system before removing the power interposer board or power distribution board.

NOTE: Ensure that the cables inside the system are correctly routed and secured using the cable securing latches.

Steps

1. Align and push the PIB to the PSU cage and slide it into place.
2. Using Phillips #2 screwdriver, tighten the screw to secure the PIB to the system.
3. Route the cables, and connect it to the system board.




Figure 109. Installing power interposer board

Next steps

1. [Install the power supply unit \(PSU\).](#)
2. Install the applicable air shroud:
 - a. [GPU air shroud](#)
 - b. [Expansion card riser 2](#)
 OR
 - a. [Expansion card riser 2](#)
 - b. [Non-GPU air shroud](#)
3. Follow the procedure listed in [After working inside your system.](#)

System board

Removing system board

Prerequisites

CAUTION: If you are using the Trusted Platform Module (TPM) with an encryption key, you may be prompted to create a recovery key during program or system setup. Be sure to create and safely store this recovery key. If you replace this system board, you must supply the recovery key when you restart your system or program before you can access the encrypted data on your drives.

CAUTION: Do not attempt to remove the TPM plug-in module from the system board. After the TPM plug-in module is installed, it is cryptographically bound to that specific system board. Any attempt to remove an installed TPM plug-in module breaks the cryptographic binding, and it cannot be reinstalled or installed on another system board.

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. Remove the following:
 - a. [Non-GPU air shroud](#) or [GPU air shroud](#)
 - b. [Cooling fan assembly.](#)

- c. [Processor and heat sink module](#)
- d. [Backplane cables](#) connected to the system board
- e. [Power interposer board \(PIB\)](#).

CAUTION: When replacing the system board, disconnect the cables from the system board, but do not disconnect the cables attached to the PIB.

- f. [Expansion card risers](#)
- g. [iDSDM/vFlash card](#)
- h. [Internal USB key](#), if installed
- i. [USB 3.0 module cable](#) connected to the system board
- j. [Processor blanks](#), if installed

CAUTION: To prevent damage to the processor socket when replacing a faulty system board, ensure that you cover the processor socket with the processor dust cover.

- k. [Network daughter card](#).
- l. [Drive cage \(rear\)](#), if installed.

Steps

1. Disconnect all cables from the system board.

CAUTION: Take care not to damage the system identification button while removing the system board from the system.

CAUTION: Do not lift the system board by holding a memory module, processor, or other components.

2. Holding the blue plungers, slide the system board to the front of the system.
3. Incline the system board at an angle, and lift the system board out of the system.




Figure 110. Removing system board

Next steps

1. [Replace or install the system board](#).

Installing system board

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. If you are replacing the system board, remove all the components listed in the [Removing the system board](#) section.

Steps

1. Unpack the replacement system board assembly.

CAUTION: Do not lift the system board by holding a memory module, processor, or other components.

CAUTION: Take care not to damage the system identification button while placing the system board into the system.

2. Holding the system board plungers, incline the system board at an angle and align the connectors on the system board with the slots on the system, and lower the system board into the system.
3. Slide the system board toward the back of the system until the plungers click into place.




Figure 111. Installing system board

Next steps

1. Replace the following:

- a. [Trusted Platform Module \(TPM\)](#)

NOTE: The TPM must be replaced only while installing a new system board.

NOTE: The TPM plug-in module is attached to the system board and cannot be removed. A replacement TPM plug-in module is provided for all system board replacements, where a TPM plug-in module was installed.

- b. [Network daughter card](#).
 - c. [Power Interposer Board \(PIB\)](#).
 - d. [USB 3.0 module cables](#), if applicable
 - e. [Backplane cables](#), if applicable
 - f. [Processor and heat sink module](#)
 - g. [Internal USB key](#), if applicable
 - h. [iDSDM/vFlash module](#)
 - i. [Expansion card risers](#)
 - j. [Cooling fan assembly](#).
 - k. [Air shroud](#).
 - l. [Drive cage \(rear\)](#), if applicable.
2. Replace the iDRAC MAC address label from the luggage tag on the front of the system with the new iDRAC MAC address label that came with the replacement system board.
 3. Reconnect all cables to the system board.

NOTE: Ensure that the cables inside the system are routed along the chassis wall and secured using the cable securing bracket.

4. Boot the system.

5. Follow the procedure listed in [After working inside your system](#).
6. Ensure that you:
 - a. Use the Easy Restore feature to restore the Service Tag. For more information, see the [Restoring the Service Tag using Easy Restore](#) section.
 - b. If the Service Tag is not backed up in the backup flash device, enter the Service Tag manually. For more information, see the [Manually update the Service Tag](#) section.
 - c. Update the BIOS and iDRAC versions.
 - d. Re-enable the Trusted Platform Module (TPM). For more information, see the [Upgrading the Trusted Platform Module \(TPM\)](#) section.
7. Import your new or existing iDRAC Enterprise license.
For more information, see iDRAC User's Guide, at Dell.com/iDRACmanuals.

Restore the service tag using Easy Restore

The Easy Restore feature allows you to restore your Service Tag, iDRAC license, UEFI configuration, and the system configuration data after replacing the system board. All data is backed up automatically in a backup flash drive device. If BIOS detects a new system board, and the Service Tag in the backup Flash device is different, BIOS prompts the user to restore the backup information.

About this task

Following is a list of options available:

1. Restore the Service Tag, iDRAC license, and diagnostics information, press **Y**.
2. Navigate to the Lifecycle Controller based restore options, press **N**.
3. Restore data from a previously created **Hardware Server Profile**, press **F10**.
 **NOTE:** When the restore process is complete, BIOS prompts to restore the system configuration data.
4. To restore the system configuration data, press **Y**
5. To use the default configuration settings, press **N**
 **NOTE:** After the restore process is complete, system reboots.
-  **NOTE:** If restoring the Service Tag is successful, you can check the Service Tag information in the **System Information** screen and compare it with the Service Tag on the system.

Manually updating Service Tag

After replacing a system board, if Easy Restore fails, follow this process to manually enter the Service Tag, using **System Setup**.

About this task

If you know the system Service Tag, use the **System Setup** menu to enter the Service Tag.

Steps

1. Turn on the system.
2. To enter the **System Setup**, press **F2**.
3. Click **Service Tag Settings**.
4. Enter the Service Tag.
 **NOTE:** You can enter the Service Tag only when the **Service Tag** field is empty. Ensure that you enter the correct Service Tag. After the Service Tag is entered, it cannot be updated or changed.
5. Click **OK**.

Trusted Platform Module

Upgrading Trusted Platform Module

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).

NOTE:

- Ensure that your operating system supports the version of the TPM being installed.
- Ensure that you download and install the latest BIOS firmware on your system.
- Ensure that the BIOS is configured to enable UEFI boot mode.

About this task

 **CAUTION:** After the TPM plug-in module is installed, it is cryptographically bound to that specific system board. Any attempt to remove an installed TPM plug-in module breaks the cryptographic binding, the removed TPM cannot be reinstalled or installed on another system board.

Removing the TPM

Steps

1. Locate the TPM connector on the system board.

 **NOTE:** To locate the TPM connector on the system board, see the [System board jumpers and connectors](#) section.

2. Press to hold down the module and remove the screw using the security Torx 8-bit shipped with the TPM module.
3. Slide the TPM module out from its connector.
4. Push the plastic rivet away from the TPM connector and rotate it 90° counterclockwise to release it from the system board.
5. Pull the plastic rivet out of its slot on the system board.

Installing the TPM

Steps

1. To install the TPM, align the edge connectors on the TPM with the slot on the TPM connector.
2. Insert the TPM into the TPM connector such that the plastic rivet aligns with the slot on the system board.
3. Press the plastic rivet until the rivet snaps into place.




Figure 112. Installing the TPM

Next steps

1. [Install the system board.](#)
2. Follow the procedure listed in [After working inside your system.](#)

Initializing TPM for BitLocker users

Steps

Initialize the TPM.

For more information, see <https://technet.microsoft.com/library/cc753140.aspx>.

The **TPM Status** changes to **Enabled, Activated**.

Initializing the TPM 1.2 for TXT users

Steps

1. While booting your system, press F2 to enter System Setup.
2. On the **System Setup Main Menu** screen, click **System BIOS > System Security Settings**.
3. From the **TPM Security** option, select **On with Pre-boot Measurements**.
4. From the **TPM Command** option, select **Activate**.
5. Save the settings.
6. Restart your system.
7. Enter **System Setup** again.
8. On the **System Setup Main Menu** screen, click **System BIOS > System Security Settings**.
9. From the **Intel TXT** option, select **On**.

Control panel

A control panel allows you to manually control the inputs to the server.

Removing left control panel

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the non-GPU air shroud](#) or [GPU air shroud](#).
4. [Remove the cooling fan assembly](#).

 **NOTE:** Ensure that you note the routing of the cables as you remove them from the system board. To prevent the cables from being pinched or crimped, route the cables properly when you replace them.

Steps

1. Open the cable latch, and disconnect the control panel cable from the system board connector.
2. Using a Phillips #1 screwdriver, remove the screws that secure the control panel and ribbon cable to the system.
3. Holding the control panel and ribbon cable, remove the control panel along with the ribbon cable away from the system.




Figure 113. Removing left control panel

Next steps

1. [Install the left control panel.](#)

Installing left control panel

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove the non-GPU air shroud or GPU air shroud](#).
4. [Remove the cooling fan assembly](#).

NOTE: Ensure that you note the routing of the cables as you remove them from the system board. To prevent the cables from being pinched or crimped, you must route the cables properly when you replace them.

Steps

1. Route the control panel cable through the side wall of the system.
2. Align the control panel assembly with the control panel slot on the system and attach the control panel assembly to the system.
3. Connect the control panel cable to the system board connector.
4. Close the cable latch to secure the control panel cable.
5. Using a Phillips #1 screwdriver, install the screws that secure the control panel and ribbon cable to the system.




Figure 114. Installing left control panel

Next steps

1. [Install the cooling fan assembly.](#)
2. [Install the non-GPU air shroud](#) or [GPU air shroud.](#)
3. Follow the procedure listed in [After working inside your system.](#)

Removing right control panel

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions.](#)
2. Follow the procedure listed in [Before working inside your system.](#)
3. [Remove front bezel](#), if installed.
4. [Remove drives, optical drive, or drive blanks](#), if installed.
5. [Remove the non-GPU air shroud](#) or [GPU air shroud.](#)
6. [Remove the cooling fan assembly.](#)

Steps

1. Disconnect the VGA cable from the system board.
2. Open the cable latch, and disconnect the control panel cable from the system board connector.
3. Using a Phillips #1 screwdriver, remove the screws that secure the control panel and ribbon cable to the system.
4. Holding the control panel and ribbon cable, remove the control panel along with the ribbon cable away from the system.




Figure 115. Removing right control panel

Next steps

1. [Replace the right control panel.](#)

Installing right control panel

Prerequisites

1. Follow the safety guidelines listed in [Safety instructions](#).
2. Follow the procedure listed in [Before working inside your system](#).
3. [Remove front bezel](#), if installed.
4. [Remove drives, optical drive, or drive blanks](#), if installed.
5. [Remove the air shroud](#).
6. [Remove the cooling fan assembly](#).

NOTE: Ensure that you note the routing of the cables as you remove them from the system board. To prevent the cables from being pinched or crimped, you must route the cables properly when you replace them.

Steps

1. Route the control panel cable and VGA cable through the side wall of the system.
2. Align the control panel with the control panel slot on the system and attach the control panel to the system.
3. Connect the VGA cable to the system board.
4. Connect the control panel cable to the system board and secure it using cable latch.
5. Using a Phillips #1 screwdriver, install the screws that secure the control panel and ribbon cable to the system.




Figure 116. Installing right control panel

Next steps

1. [Install the cooling fan assembly.](#)
2. [Install the non-GPU air shroud](#) or [GPU air shroud](#).
3. [Install the drives, optical drives, or drive blanks](#), if applicable.
4. [Install the front bezel](#), if applicable.
5. Follow the procedure listed in [After working inside your system](#).

Jumpers and connectors

This topic provides specific information about the jumpers. It also provides some basic information about jumpers and switches and describes the connectors on the various boards in the system. Jumpers on the system board help to disable the system and setup passwords. You must know the connectors on the system board to install components and cables correctly.

Topics:

- [System board connectors](#)
- [System board jumper settings](#)
- [Disable a forgotten password](#)

System board connectors

The following diagram and table describe the system board connectors and jumpers.




Figure 117. System board connectors

Table 18. System board jumpers and connectors

Item	Connector	Description
1	D7, D1, D8, D2, D9, D3	Memory module sockets
2	J_ODD	Optical drive power connector
3	J_FAN_6	Cooling fan 6 connector

Table 18. System board jumpers and connectors (continued)

Item	Connector	Description
4	CPU4	CPU4 processor and heat sink module socket— with dust cover
5	J_BP_PWR0	Backplane power connector
6	J_FAN_5	Cooling fan 5 connector
7	J_BP_SIG_B	Backplane B signal connector (rear)
8	D6, D12, D5, D11, D4, D10	Memory module sockets
9	J_FAN_4	Cooling fan 4 connector
10	C7, C1, C8, C2, C9, C3	Memory module sockets
11	J_FAN_3	Cooling fan 3 connector
12	CPU3	CPU3 processor and heat sink module socket— with dust cover
13	J_FAN_2	Cooling fan 2 connector
14	J_BP_SIG_A	Backplane A signal connector (front)
15	C6, C12, C5, C11, C4, C10	Memory module sockets
16	J_BP_PWR1	Backplane power connector
17	J_FAN_1	Cooling fan 1 connector
18	PCIe_M3	PCIe Signal M3 connector
19	PCIe_M1	PCIe Signal M1 connector
20	PCIe_M2	PCIe Signal M2 connector
21	CPU2	CPU2 processor and heat sink module socket— with dust cover
22	B3, B9, B2, B8, B1, B7	Memory module sockets
23	B10, B4, B11, B5, B12, B6	Memory module sockets
24	J_PIB_SIG1	Power Interposer Board signal connector
25	J_RISER2	PCIe riser 2 connector
26	J_PIB_PWR 4	PIB power connector 4
27	J_PIB_PWR 3	PIB power connector 3
28	J_PIB_PWR 2	PIB power connector 2
29	J_PIB_PWR 1	PIB power connector 1
30	U_USB_RECONN	USB Client power management
31	J_BATT_PWR	NVDIMM-N battery power connector
32	J_BATT_SIG	NVDIMM-N battery signal connector
33	J_TPM_MODULE	TPM connector
34	CMOS Battery	CMOS Battery connector
35	J_SLOT4	PCIe x16 connector
36	J_SLOT3	PCIe x16 connector
37	J_USB_INT	Internal USB connector
38	J_SATA_1	NPIO connector1 for x8 backplane

Table 18. System board jumpers and connectors (continued)

Item	Connector	Description
39	J_NDC	NDC connector
40	J_RISER1	PCIe riser 1 connector
41	J_SATA_2	NPIO connector 2 for x8 backplane
42	J_PSWD	Reset BIOS password
43	NVRAM_CLR	Clear NVRAM
44	J_FRONT_VIDEO	Video connector
45	J_SATA_3	SATA C connector—Optical drive SATA connector
46	A3, A9, A2, A8, A1, A7	Memory module sockets
47	A10, A4, A11, A5, A12, A6	Memory module sockets
48	CPU1	CPU1 processor and heat sink module socket— with dust cover
49	PCIe_M5	PCIe Signal M5 connector
50	PCIe_M6	PCIe Signal M6 connector
51	PCIe_M4	PCIe Signal M4 connector

CAUTION: When replacing the system board, disconnect the cables from the system board, but do not disconnect the cables attached to the PIB.

System board jumper settings

For information on resetting the password jumper to disable a password, see the Disabling a forgotten password section.

Table 19. System board jumper settings

Jumper	Setting	Description
PWRD_EN	 2 4 6 (default)	The BIOS password feature is enabled.
	 2 4 6	The BIOS password feature is disabled. iDRAC local access is unlocked at next AC power cycle. iDRAC password reset is enabled in F2 iDRAC settings menu.
NVRAM_CLR	 1 3 5 (default)	The BIOS configuration settings are retained at system boot.
	 1 3 5	The BIOS configuration settings are cleared at system boot.

CAUTION: Be careful when altering BIOS settings. The BIOS interface is designed for advanced users, you can change a setting that could prevent your computer from starting correctly and you could suffer a potential loss of data.

1. Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
2. Remove the system cover.
3. Move the jumper (NVRAM_CLR) on the system board jumper from pins 3 and 5 to pins 1 and 3 and wait approximately 10 seconds. Move the 2-pin jumper (PWRD_EN) plug from the password jumper to pins into the CMOS jumper.
4. Replace the jumper plug on pins 3 and 5.
5. Install the system cover. Plug in AC Power to the system and wait ten seconds for the CMOS to clear, reconnect the system to its electrical outlet and turn on the system, including any attached peripherals.

Disable a forgotten password

The software security features of the system include a system password and a setup password. The password jumper enables or disables password features and clears any password(s) currently in use.

Prerequisites

 **CAUTION:** Many repairs may only be done by a certified service technician. You should only perform troubleshooting and simple repairs as authorized in your product documentation, or as directed by the online or telephone service and support team. Damage due to servicing that is not authorized by Dell is not covered by your warranty. Read and follow the safety instructions that are shipped with your product.

Steps

1. Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
2. Remove the system cover.
3. Move the jumper on the system board jumper from pins 2 and 4 to pins 4 and 6.
4. Install the system cover.

The existing passwords are not disabled (erased) until the system boots with the jumper on pins 4 and 6. However, before you assign a new system and/or setup password, you must move the jumper back to pins 2 and 4.

 **NOTE:** If you assign a new system and/or setup password with the jumper on pins 4 and 6, the system disables the new password(s) the next time it boots.

5. Reconnect the system to its electrical outlet and turn on the system, including any attached peripherals.
6. Turn off the system, including any attached peripherals, and disconnect the system from the electrical outlet.
7. Remove the system cover.
8. Move the jumper on the system board jumper from pins 4 and 6 to pins 2 and 4.
9. Install the system cover.
10. Reconnect the system to its electrical outlet and turn on the system, including any attached peripherals.
11. Assign a new system and/or setup password.

System diagnostics and indicator codes

The diagnostic indicators on the system front panel display system status during system startup.

Topics:

- [Status LED indicators](#)
- [System health and system ID indicator codes](#)
- [iDRAC Quick Sync 2 indicator codes](#)
- [iDRAC Direct LED indicator codes](#)
- [NIC indicator codes](#)
- [Power supply unit indicator codes](#)
- [Drive indicator codes](#)
- [System diagnostics](#)

Status LED indicators

 **NOTE:** The indicators display solid amber if any error occurs.

Table 20. Status LED indicators and descriptions

Icon	Description	Condition	Corrective action
	Drive indicator	The indicator turns solid amber if there is a drive error.	• Check the System Event Log to determine if the drive has an error. • Run the appropriate Online Diagnostics test. Restart the system and run embedded diagnostics (ePSA). • If the drives are configured in a RAID array, restart the system, and enter the host adapter configuration utility program.
	Temperature indicator	The indicator turns solid amber if the system experiences a thermal error (for example, the ambient temperature is out of range or there is a fan failure).	Ensure that none of the following conditions exist: • A cooling fan has been removed or has failed. • System cover, air shroud, memory module blank, or back filler bracket is removed. • Ambient temperature is too high. • External airflow is obstructed. If the problem persists, see Getting help.
	Electrical indicator	The indicator turns solid amber if the system experiences an electrical error (for example, voltage out of range, or a failed power supply unit (PSU) or voltage regulator).	Check the System Event Log or system messages for the specific issue. If it is due to a problem with the PSU, check the LED on the PSU. Reseat the PSU. If the problem persists, see Getting help.
	Memory indicator	The indicator turns solid amber if a memory error occurs.	Check the System Event Log or system messages for the location of the failed memory. Reseat the memory module. If the problem persists, see Getting help.
	PCIe indicator	The indicator turns solid amber if a PCIe card experiences an error.	Restart the system. Update any required drivers for the PCIe card. Reinstall the card. If the problem persists, see Getting help.  NOTE: For more information about the supported PCIe cards, see Expansion card installation guidelines.

System health and system ID indicator codes

The system health and system ID indicator is located on the left control panel of your system.



Figure 118. System health and system ID indicators

Table 21. System health and system ID indicator codes

System health and system ID indicator code	Condition
Solid blue	Indicates that the system is turned on, system is healthy, and system ID mode is not active. Press the system health and system ID button to switch to system ID mode.
Blinking blue	Indicates that the system ID mode is active. Press the system health and system ID button to switch to system health mode.
Solid amber	Indicates that the system is in fail-safe mode. If the problem persists, see the Getting help section.
Blinking amber	Indicates that the system is experiencing a fault. Check the System Event Log or the LCD panel, if available on the bezel, for specific error messages. For more information about error messages, see the <i>Dell Event and Error Messages Reference Guide</i> at https://www.dell.com/openmanagemanuals .

iDRAC Quick Sync 2 indicator codes

iDRAC Quick Sync 2 module (optional) is located on the left control panel of your system.



Figure 119. iDRAC Quick Sync 2 indicators

Table 22. iDRAC Quick Sync 2 indicators and descriptions

iDRAC Quick Sync 2 indicator code	Condition	Corrective action
Off (default state)	Indicates that the iDRAC Quick Sync 2 feature is turned off. Press the iDRAC Quick Sync 2 button to turn on the iDRAC Quick Sync 2 feature.	If the LED fails to turn on, reseal the left control panel flex cable and check. If the problem persists, see the Getting help section.
Solid white	Indicates that iDRAC Quick Sync 2 is ready to communicate. Press the iDRAC Quick Sync 2 button to turn off.	If the LED fails to turn off, restart the system. If the problem persists, see the Getting help section.
Blinks white rapidly	Indicates data transfer activity.	If the indicator continues to blink indefinitely, see the Getting help section.
Blinks white slowly	Indicates that firmware update is in progress.	If the indicator continues to blink indefinitely, see the Getting help section.
Blinks white five times rapidly and then turns off	Indicates that the iDRAC Quick Sync 2 feature is disabled.	Check if iDRAC Quick Sync 2 feature is configured to be disabled by iDRAC. If the problem persists, see the Getting help section.

Table 22. iDRAC Quick Sync 2 indicators and descriptions (continued)

iDRAC Quick Sync 2 indicator code	Condition	Corrective action
Solid amber	Indicates that the system is in fail-safe mode.	For more information, see <i>Integrated Dell Remote Access Controller User's Guide</i> at www.dell.com/idracmanuals or <i>Dell OpenManage Server Administrator User's Guide</i> at www.dell.com/openmanagemanuals .
Blinking amber	Indicates that the iDRAC Quick Sync 2 hardware is not responding properly.	Restart the system. If the problem persists, see the Getting help section.

iDRAC Direct LED indicator codes

The iDRAC Direct LED indicator lights up to indicate that the port is connected and is being used as a part of the iDRAC subsystem.


You can configure iDRAC Direct by using a USB to micro USB (type AB) cable, which you can connect to your laptop or tablet. The following table describes iDRAC Direct activity when the iDRAC Direct port is active:

Table 23. iDRAC Direct LED indicator codes

iDRAC Direct LED indicator code	Condition
Solid green for two seconds	Indicates that the laptop or tablet is connected.
Flashing green (on for two seconds and off for two seconds)	Indicates that the laptop or tablet connected is recognized.
Turns off	Indicates that the laptop or tablet is unplugged.

NIC indicator codes

Each NIC on the back of the system has indicators that provide information about the activity and link status. The activity LED indicator indicates if data is flowing through the NIC, and the link LED indicator indicates the speed of the connected network.

**Figure 120. NIC indicator codes**

1. Link LED indicator
2. Activity LED indicator

Table 24. NIC indicator codes

Status	Condition
Link and activity indicators are off.	The NIC is not connected to the network.
Link indicator is green, and activity indicator is blinking green.	The NIC is connected to a valid network at its maximum port speed, and data is being sent or received.

Table 24. NIC indicator codes (continued)

Status	Condition
Link indicator is amber, and activity indicator is blinking green.	The NIC is connected to a valid network at less than its maximum port speed, and data is being sent or received.
Link indicator is green, and activity indicator is off.	The NIC is connected to a valid network at its maximum port speed, and data is not being sent or received.
Link indicator is amber, and activity indicator is off.	The NIC is connected to a valid network at less than its maximum port speed, and data is not being sent or received.
Link indicator is blinking green, and activity is off.	NIC identify is enabled through the NIC configuration utility.


Power supply unit indicator codes

AC power supply units (PSUs) have an illuminated translucent handle that serves as an indicator. The DC PSUs have an LED that serves as an indicator.

For more information about the PSU specifications, see the PowerEdge R840 Technical Specs at www.dell.com/poweredgemanuals.

For information about the event and error messages generated during POST, when a 2400W PSU is connected to a 110 V power source, see the Dell Event and Error Messages Reference Guide at <https://www.dell.com/openmanagemanuals>.

The indicator shows whether power is present or if a power fault has occurred.

**Figure 121. AC PSU status indicator**

1. AC PSU status indicator/handle

Table 25. AC PSU status indicator codes

Power indicator codes	Condition
Green	A valid power source is connected to the PSU, and the PSU is operational.
Blinking amber	Indicates a problem with the PSU.
Not illuminated	Power is not connected to the PSU.
Blinking green	When the firmware of the PSU is being updated, the PSU handle blinks green. CAUTION: Do not disconnect the power cable, or unplug the PSU when updating firmware. If firmware update is interrupted, the PSUs do not function.
Blinking green and turns off	When hot-plugging a PSU, the PSU handle blinks green five times at a rate of 4 Hz and turns off. This indicates a PSU mismatch concerning efficiency, feature set, health status, or supported voltage. CAUTION: If two PSUs are installed, both the PSUs must have the same type of label; for example, Extended Power Performance (EPP) label. Mixing PSUs from previous generations of PowerEdge

Table 25. AC PSU status indicator codes (continued)

Power indicator codes	Condition
	servers is not supported, even if the PSUs have the same power rating. This results in a PSU mismatch condition, or failure to turn on the system. ⚠ CAUTION: When correcting a PSU mismatch, replace only the PSU with the blinking indicator. Swapping the PSU to make a matched pair can result in an error condition and unexpected system shutdown. To change from a high output configuration to a low output configuration or conversely, you must turn off the system. ⚠ CAUTION: AC PSUs support both 240 V and 120 V input voltages except for Titanium PSUs, which support only 240 V. When two identical PSUs receive different input voltages, they can output different wattages, and trigger a mismatch. ⚠ CAUTION: If two PSUs are used, they must be of the same type and have the same maximum output power. ⚠ CAUTION: Combining AC and DC PSUs is not supported and triggers a mismatch.




Figure 122. DC PSU status indicator

1. DC PSU status indicator

Table 26. DC PSU status indicator codes

Power indicator codes	Condition
Green	A valid power source is connected to the PSU, and the PSU is operational.
Blinking amber	Indicates a problem with the PSU.
Not illuminated	Power is not connected to the PSU.
Blinking green	When hot-plugging a PSU, the PSU indicator blinks green. This indicates that there is a PSU mismatch about efficiency, feature set, health status, or supported voltage.

Table 26. DC PSU status indicator codes (continued)

Power indicator codes	Condition
	⚠ CAUTION: If two PSUs are installed, both the PSUs must have the same type of label; for example, Extended Power Performance (EPP) label. Mixing PSUs from previous generations of PowerEdge servers is not supported, even if the PSUs have the same power rating. This results in a PSU mismatch condition, or failure to turn on the system. ⚠ CAUTION: When correcting a PSU mismatch, replace only the PSU with the blinking indicator. Swapping the PSU to make a matched pair can result in an error condition and unexpected system shutdown. To change from a High Output configuration to a Low Output configuration or conversely, you must turn off the system. ⚠ CAUTION: If two PSUs are used, they must be of the same type and have the same maximum output power. ⚠ CAUTION: Combining AC and DC PSUs is not supported and triggers a mismatch.

Drive indicator codes

The LEDs on the drive carrier indicates the state of each drive. Each drive carrier in your system has two LEDs: an activity LED (green) and a status LED (bicolor, green/amber). The activity LED flashes whenever the drive is accessed.



Figure 123. Drive indicators on the drive and the mid drive tray backplane

1. Drive activity LED indicator
2. Drive status LED indicator
3. Drive capacity label

NOTE: If the drive is in the Advanced Host Controller Interface (AHCI) mode, the status LED indicator does not turn on.

Table 27. Drive indicator codes

Drive status indicator code	Condition
Flashes green twice per second	Identifying drive or preparing for removal.
Off	Drive ready for removal.

Table 27. Drive indicator codes (continued)

Drive status indicator code	Condition
	 NOTE: The drive status indicator remains off until all drives are initialized after the system is turned on. Drives are not ready for removal during this time.
Flashes green, amber, and then turns off	Predicted drive failure.
Flashes amber four times per second	Drive failed.
Flashes green slowly	Drive rebuilding.
Solid green	Drive online.
Flashes green for three seconds, amber for three seconds, and then turns off after six seconds	Rebuild stopped.

System diagnostics

If you experience a problem with your system, run the system diagnostics before contacting Dell for technical assistance. The purpose of running system diagnostics is to test your system hardware without using additional equipment or risking data loss. If you are unable to fix the problem yourself, service and support personnel can use the diagnostics results to help you solve the problem.

Dell Embedded System Diagnostics

 **NOTE:** The Dell Embedded System Diagnostics is also known as Enhanced Pre-boot System Assessment (ePSA) diagnostics.

The Embedded System Diagnostics provides a set of options for particular device groups or devices allowing you to:

- Run tests automatically or in an interactive mode
- Repeat tests
- Display or save test results
- Run thorough tests to introduce additional test options to provide extra information about the failed device(s)
- View status messages that inform you if tests are completed successfully
- View error messages that inform you of problems encountered during testing

Running the Embedded System Diagnostics from Boot Manager

Run the Embedded System Diagnostics (ePSA) if your system does not boot.

Steps

1. When the system is booting, press F11.
2. Use the up arrow and down arrow keys to select **System Utilities > Launch Diagnostics**.
3. Alternatively, when the system is booting, press F10, select **Hardware Diagnostics > Run Hardware Diagnostics**. The **ePSA Pre-boot System Assessment** window is displayed, listing all devices detected in the system. The diagnostics starts executing the tests on all the detected devices.

Running the Embedded System Diagnostics from the Dell Lifecycle Controller

Steps

1. As the system boots, press F10.
2. Select **Hardware Diagnostics → Run Hardware Diagnostics**.

The **ePSA Pre-boot System Assessment** window is displayed, listing all devices detected in the system. The diagnostics starts executing the tests on all the detected devices.

System diagnostic controls

Menu	Description
Configuration	Displays the configuration and status information of all detected devices.
Results	Displays the results of all tests that are run.
System health	Provides the current overview of the system performance.
Event log	Displays a time-stamped log of the results of all tests run on the system. This is displayed if at least one event description is recorded.

Getting help

Topics:

- [Contacting Dell](#)
- [Documentation feedback](#)
- [Accessing system information by using QRL](#)
- [Receiving automated support with SupportAssist](#)
- [Quick Resource Locator for PowerEdge R840 system](#)
- [Recycling or End-of-Life service information](#)

Contacting Dell

Dell provides several online and telephone based support and service options. If you do not have an active internet connection, you can find contact information about your purchase invoice, packing slip, bill, or Dell product catalog. Availability varies by country and product, and some services may not be available in your area. To contact Dell for sales, technical assistance, or customer service issues:

Steps

1. Go to www.dell.com/support/home
2. Select your country from the drop-down menu on the lower right corner of the page.
3. For customized support:
 - a. Enter your system Service Tag in the **Enter your Service Tag** field.
 - b. Click **Submit**.
The support page that lists the various support categories is displayed.
4. For general support:
 - a. Select your product category.
 - b. Select your product segment.
 - c. Select your product.
The support page that lists the various support categories is displayed.
5. For contact details of Dell Global Technical Support:
 - a. Click [Contact Technical Support](#)
 - b. The **Contact Technical Support** page is displayed with details to call, chat, or e-mail the Dell Global Technical Support team.

Documentation feedback

You can rate the documentation or write your feedback on any of our Dell EMC documentation pages and click **Send Feedback** to send your feedback.

Accessing system information by using QRL

You can use the Quick Resource Locator (QRL) to get immediate access to the information about your system.

Prerequisites

Ensure that your smart phone or tablet has the QR code scanner installed.

The QRL includes the following information about your system:

- How-to videos
- Reference materials, including the Owner's Manual, LCD diagnostics, and mechanical overview
- Service Tag to quickly access the specific hardware configuration and warranty information
- A direct link to Dell to contact technical support and sales teams

Steps

1. Go to www.dell.com/qrl, and navigate to your specific product or
2. Use your smart phone or tablet to scan the model-specific Quick Resource (QR) code on your Dell system or in the [Quick Resource Locator](#) section.

Receiving automated support with SupportAssist

Dell EMC SupportAssist is an optional Dell EMC Services offering that automates technical support for your Dell EMC server, storage, and networking devices. By installing and setting up a SupportAssist application in your IT environment, you can receive the following benefits:

- **Automated issue detection** — SupportAssist monitors your Dell EMC devices and automatically detects hardware issues, both proactively and predictively.
- **Automated case creation** — When an issue is detected, SupportAssist automatically opens a support case with Dell EMC Technical Support.
- **Automated diagnostic collection** — SupportAssist automatically collects system state information from your devices and uploads it securely to Dell EMC. This information is used by Dell EMC Technical Support to troubleshoot the issue.
- **Proactive contact** — A Dell EMC Technical Support agent contacts you about the support case and helps you resolve the issue.

The available benefits vary depending on the Dell EMC Service entitlement purchased for your device. For more information about SupportAssist, go to www.dell.com/supportassist.

Quick Resource Locator for PowerEdge R840 system



Figure 124. Quick Resource Locator for PowerEdge R840 system

Recycling or End-of-Life service information

Take back and recycling services are offered for this product in certain countries. If you want to dispose of system components, visit www.dell.com/recyclingworldwide and select the relevant country.

Documentation resources

This section provides information about the documentation resources for your system.

To view the document that is listed in the documentation resources table:

- From the Dell EMC support site:
 1. Click the documentation link that is provided in the Location column in the table.
 2. Click the required product or product version.
-  **NOTE:** To locate the product name and model, see the front of your system.
- 3. On the Product Support page, click **Manuals & documents**.
- Using search engines:
 - Type the name and version of the document in the search box.

Table 28. Documentation resources

Task	Document	Location
Setting up your system	For more information about installing and securing the system into a rack, see the Rail Installation Guide included with your rack solution. For information about setting up your system, see the <i>Getting Started Guide</i> document that is shipped with your system.	https://www.dell.com/poweredgemanuals
Configuring your system	For information about the iDRAC features, configuring and logging in to iDRAC, and managing your system remotely, see the Integrated Dell Remote Access Controller User's Guide. For information about understanding Remote Access Controller Admin (RACADM) subcommands and supported RACADM interfaces, see the RACADM CLI Guide for iDRAC. For information about Redfish and its protocol, supported schema, and Redfish Eventing implemented in iDRAC, see the Redfish API Guide. For information about iDRAC property database group and object descriptions, see the Attribute Registry Guide. For information about Intel QuickAssist Technology, see the Integrated Dell Remote Access Controller User's Guide.	https://www.dell.com/poweredgemanuals
	For information about earlier versions of the iDRAC documents. To identify the version of iDRAC available on your system, on the iDRAC web interface, click ? > About.	https://www.dell.com/idracmanuals
	For information about installing the operating system, see the operating system documentation.	https://www.dell.com/operatingsystemmanuals

Table 28. Documentation resources (continued)

Task	Document	Location
	For information about updating drivers and firmware, see the Methods to download firmware and drivers section in this document.	www.dell.com/support/drivers
Managing your system	For information about system management software offered by Dell, see the Dell OpenManage Systems Management Overview Guide.	https://www.dell.com/poweredgemanuals
	For information about setting up, using, and troubleshooting OpenManage, see the Dell OpenManage Server Administrator User's Guide.	www.dell.com/openmanagemanuals > OpenManage Server Administrator
	For information about installing, using, and troubleshooting Dell OpenManage Enterprise, see the Dell OpenManage Enterprise User's Guide.	https://www.dell.com/openmanagemanuals
	For information about installing and using Dell SupportAssist, see the Dell EMC SupportAssist Enterprise User's Guide.	https://www.dell.com/serviceabilitytools
	For information about partner programs enterprise systems management, see the OpenManage Connections Enterprise Systems Management documents.	https://www.dell.com/openmanagemanuals
Working with the Dell PowerEdge RAID controllers	For information about understanding the features of the Dell PowerEdge RAID controllers (PERC), Software RAID controllers, or BOSS card and deploying the cards, see the Storage controller documentation.	www.dell.com/storagecontrollermanuals
Understanding event and error messages	For information about the event and error messages generated by the system firmware and agents that monitor system components, go to qrl.dell.com > Look Up > Error Code , type the error code, and then click Look it up .	www.dell.com/qrl
Troubleshooting your system	For information about identifying and troubleshooting the PowerEdge server issues, see the Server Troubleshooting Guide.	https://www.dell.com/poweredgemanuals